PCIS-8580-4S
PCIS-8580-13S
User's Manual

Manual Rev. 2.04

Revision Date: November 15, 2010

Part No: 50-15054-1020

Recycled Paper

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Advance Technologies; Automate the World.

Copyright 2009, 2010 ADLINK TECHNOLOGY INC.

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Trademarks

Product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Getting Service from ADLINK

Contact us should you require any service or assistance.

ADLINK Technology, Inc.
Address: 9F, No.166 Jian Yi Road, Chungho City,
Taipei County 235, Taiwan
台北縣中和市建一路 166 號 9 樓
Tel: +886-2-8226-5877
Fax: +886-2-8226-5717
Email: service@adlinktech.com

Ampro ADLINK Technology, Inc.
Address: 5215 Hellyer Avenue, #110, San Jose, CA 95138, USA
Tel: +1-408-360-0200
Toll Free: +1-800-966-5200 (USA only)
Fax: +1-408-360-0222
Email: info@adlinktech.com

ADLINK Technology (China) Co., Ltd.
Address: 上海市浦东新区张江高科技园区芳春路 300 号 (201203)
300 Fang Chun Rd., Zhangjiang Hi-Tech Park,
Pudong New Area, Shanghai, 201203 China
Tel: +86-21-5132-8988
Fax: +86-21-5132-3588
Email: market@adlinktech.com

ADLINK Technology Beijing
Address: 北京市海淀区上地东路 1 号盈创动力大厦 E 座 801 室(100085)
Rm. 801, Power Creative E, No. 1, B/D
Shang Di East Rd., Beijing, 100085 China
Tel: +86-10-5885-8666
Fax: +86-10-5885-8625
Email: market@adlinktech.com

ADLINK Technology Shenzhen
Address: 深圳市南山区科技园南区高新南七道 数字技术园
A1 栋 2 楼 C 区 (518057)
2F, C Block, Bldg. A1, Cyber-Tech Zone, Gao Xin Ave. Sec. 7,
High-Tech Industrial Park S., Shenzhen, 518054 China
Tel: +86-755-2643-4858
Fax: +86-755-2664-6353
Email: market@adlinktech.com

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

ADLINK Technology (Europe) GmbH
Address: Nord Carree 3, 40477 Duesseldorf, Germany
Tel: +49-211-495-5552
Fax: +49-211-495-5557
Email: emea@adlinktech.com

ADLINK Technology, Inc. (French Liaison Office)
Address: 15 rue Emile Baudot, 91300 Massy CEDEX, France
Tel: +33 (0) 1 60 12 35 66
Fax: +33 (0) 1 60 12 35 66
Email: france@adlinktech.com

ADLINK Technology Japan Corporation
Address: 151-0072 東京都渋谷区幡ヶ谷
1-1-2 朝日生命幡ヶ谷ビル 8F
Asahiseimei Hatagaya Bldg. 8F
1-1-2 Hatagaya, Shibuya-ku, Tokyo 151-0072, Japan
Tel: +81-3-4455-3722
Fax: +81-3-5333-6040
Email: japan@adlinktech.com

ADLINK Technology, Inc. (Korean Liaison Office)
Address: 서울시 서초구 서초동 1506-25 한도 B/D 2 층
2F, Hando B/D, 1506-25, Seocho-Dong, Seocho-Gu,
Seoul 137-070, Korea
Tel: +82-2-2057-0565
Fax: +82-2-2057-0563
Email: korea@adlinktech.com

ADLINK Technology Singapore Pte. Ltd.
Address: 84 Genting Lane #07-02A, Cityneon Design Centre,
Singapore 349584
Tel: +65-6844-2261
Fax: +65-6844-2263
Email: singapore@adlinktech.com

ADLINK Technology Singapore Pte. Ltd. (Indian Liaison Office)
Address: No. 1357, "Anupama", Sri Aurobindo Marg, 9th Cross,
JP Nagar Phase I, Bangalore - 560078, India
Tel: +91-80-65605817
Fax: +91-80-22443548
Email: india@adlinktech.com

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Table of Contents

Table of Contents i

List of Tables iii

List of Figures iv

1 Introduction 1
- 1.1 Features 2
  - PCIS-8580-4S 2
  - PCIS-8580-13S 2
- 1.2 Applications 2
- 1.3 Specifications 3
  - LPCI-8575 PCI-PCI Expansion Card 3
  - RK-8005 Expansion chassis 4
  - RK-8014 Expansion chassis 5
  - ACL-PCIEXT-2 Cable 5
  - General 5

2 Installation 7
- 2.1 Content of package 7
- 2.2 Unpacking 8
- 2.3 Getting Start 8
  - Install PCI Expansion Card into your Host System 8
  - Driver Installation 9
  - Install your PCI Card into the Expansion Chassis 10
  - Connect to Expansion Chassis 12
  - Power-on Sequence 12

3 Hardware Overview 13
- 3.1 System Architecture 13
  - Operation Theory 13
- 3.2 LPCI-8575 PCI Expansion Card 14
  - Functional Block 14
  - Jumper Settings for LPCI-8575 15
- 3.3 BP-8005 19
  - Backplane Architecture 19
  - Jumpers and Connectors 22
  - Jumpers and connectors on the bottom side 22

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.4 RK-8005 23
Mechanical Drawing of RK-8005 23
3.5 BP-8014 24
Backplane Architecture 24
Jumpers and Connectors 25
3.6 RK-8014 26
Mechanical Drawing of RK-8014 26
3.7 ACL-PCIEXT-2 27
Pin Assignment of ACL-PCIEXT-2 27

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

List of Tables

Table 1-1: Power requirements 3
Table 3-1: Jumpers and connectors on the LPCI-8575 15
Table 3-2: JP1 Settings 16
Table 3-3: JP2 Settings 16
Table 3-4: JP3 Settings 17
Table 3-5: D2 Display 18
Table 3-6: Top side jumpers and connectors 22
Table 3-7: Bottom side jumpers and connectors 22
Table 3-8: BP-8014 jumpers and connectors 25
Table 3-9: Pin Assignment of ACL-PCIEXT-2 27

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

List of Figures

Figure 2-1: Install the PCI expansion card into your host system 9
Figure 2-2: Installing the driver for PCI expansion card 10
Figure 2-3: Install your PCI cards into the expansion chassis (using the PCIS-8580-4S as an example) 11
Figure 2-4: Connect you host computer and expansion chassis (using the PCIS-8580-4S as an example) 12
Figure 3-1: Operation theory of PCIS-8580 PCI-to-PCI expansion system 13
Figure 3-2: Concept of the serialized PCI bridge 14
Figure 3-3: Jumpers and connectors on the LPCI-8575 15
Figure 3-4: Top view of BP-8005 backplane 20
Figure 3-5: Bottom view of BP-8005 backplane 21
Figure 3-6: Mechanical drawing of RK-8005 23
Figure 3-7: Top view of BP-8014 backplane 24
Figure 3-8: Mechanical drawing of RK-8014 26
Figure 3-9: DVI Connector pins and dimensions 27

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1 Introduction

The ADLINK PCIS-8580 is the PCI-to-PCI expansion systems for extending your PCI buses of the host computers. With the state-of-art StarFabric high-speed serial link technology, you can extend your PCI bus of the host computer to an external chassis, which accommodates 4 (PCIS-8580-4S) or 13 (PCIS-8580-13S) additional PCI slots. This advanced technology provides full 32-bit/33MHz PCI bandwidth (132MB/s) and maximal 10m distance between host computer and expansion chassis. In addition, ADLINK PCI-to-PCI expansion system utilizes the concept of “serialized bridge” to provide complete hardware and software transparency to your host system. Any hardware installed in the expansion chassis works as it’s inside the host system without any driver/software effort.

The ADLINK PCIS-8580 PCI-to-PCI expansion system is composed of three major components: a PCI expansion card (LPCI-8575), an expansion chassis (RK-8005 for PCIS-8580-4S or RK-8014 for PCIS-8580-13S), and a cable (ACL-PCIEXT-2). The PCI expansion card is the core of this system. It acts as a PCI bridge with the capability to serialize the PCI signals and maintain a 5Gbps serial link between the host system and the expansion chassis. The expansion chassis, which is a 4-slot wall-mount chassis (RK-8005) or a 13-slot rack-mount chassis (RK-8014), is the platform to accommodate PCI slots. It contains a backplane, a power supply, and a pre-installed PCI expansion card. The cable, which consists of DVI-D connector and shielding twisted pairs, provides robust connectivity and satisfying signal quality between the host computer and the expansion chassis.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.1 Features

PCIS-8580-4S

- PCI local bus specification Rev 2.2 compliant
- PCI bridge architecture specification Rev 1.2 compliant
- Provides 4 extended half-size PCI slots
- Full 32-bit/33MHz PCI bandwidth expansion (132MB/s)
- Maximal 10m expansion distance
- Complete hardware and software transparency
- 24-pin DVI-D connector for robust connectivity
- Shoebox size wall-mount chassis with built-in 200W power supply

PCIS-8580-13S

- PCI local bus specification Rev 2.2 compliant
- PCI bridge architecture specification Rev 1.2 compliant
- Provides 13 extended full-size PCI slots
- Full 32-bit/33MHz PCI bandwidth expansion (132MB/s)
- Maximum 10m expansion distance
- Complete hardware and software transparency
- 24-pin DVI-D connector for robust connectivity
- 19” rack-mound chassis with built-in 400W power supply

1.2 Applications

- Industrial automation/control
- Electronics manufacturing test
- Military/aerospace
- Video capture
- Remote test and measurement

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.3 Specifications

LPCI-8575 PCI-PCI Expansion Card

- PCI local bus specification Rev 2.2 compliant
- PCI bridge architecture specification Rev 1.2 compliant
- Supports both 5V and 3.3V PCI bus
- Data throughput: full 32-bit/33MHz PCI bandwidth (132MB/s)
- I/O connector: DVI-D 24-pin connector
- Link indicator (Green LED)
  - Off: Expansion or host computer does not power on
  - On: Link status is good
  - Blink: Link status is failed. Check your cable or power-on sequence.
- Maximum extended distance: 10m
- Power requirements

+5V	+3.3V
190mA	250mA

Table 1-1: Power requirements

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

RK-8005 Expansion chassis

- Dimensions: 122mm(W) x 195mm(H) x 260mm(D)
- Weight: 3.2 Kg (7.04lb)
- Backplane: 5x 32-bit/33MHz half-size PCI slots
  - 1 slot for expansion card
  - 4 slots available for PCI cards
- Front-panel indicators
  - Power indicator (Red LED)
  - Link indicator (Green LED)

    Off: Expansion or host computer does not power on

    On: Link status is good

    Blink: Link status is failed. Check your cable or power-on sequence.
- Power supply
  - Input voltage: 85VAC to 265VAC, auto-switching
  - Output: 200W
- Cooling: One 37.5 CFM ball bearing fan (80mm)

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

RK-8014 Expansion chassis

- Dimensions: 438.5mm(W) x 177mm(H) x 448.5mm(D)
- Weight: 12 kg (26.4lb)
- Backplane: 14x 32-bit/33MHz full-size PCI slots
  - 1 slot for expansion card
  - 13 slots available for PCI cards
- Front-panel indicators
  - Power indicator (Red LED)
  - Link indicator (Green LED)

    Off: Expansion or host computer does not power on

    On: Link status is good

    Blink: Link status is failed. Check your cable or power-on sequence.
- Power supply
  - Input voltage: 85VAC to 265VAC, auto-switching
  - Output: 400W
- Cooling: Two 88 CFM ball bearing fan (120mm)

ACL-PCIEXT-2 Cable

- Length: 2m
- Construction: 8 pairs of shielding twisted copper wires
- Connector: DVI-D 24-pin
- Other cable options
  - ACL-PCIEXT-5: 5m
  - ACL-PCIEXT-10: 10m

General

- Operating temperature: 0°C to 50°C
- Storage temperature : -20°C to 80°C
- Relative humidity: 10 to 90%, non-condensing

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2 Installation

This chapter outlines the contents of package, describes unpacking information, and describes how to set up the PCIS-8580 PCI-to-PCI expansion system and install your PCI cards.

2.1 Content of package

PCIS-8580-4S package includes the following items:

- One LPCI-8575 in a individual carton
- One wall-mount chassis, which contains the following components pre-installed:
  - One LPCI-8575
  - One 5-slot backplane
  - One 200W AC power supply
- One ACL-PCIEXT-2 cable
- One AC power cord
- Wall-mount kit for chassis
- This User's Manual

PCIS-8580-13S package includes the following items:

- One LPCI-8575 in a individual carton
- One rack-mount chassis, which contains the following components pre-installed:
  - One LPCI-8575
  - One 14-slot backplane
  - One 400W AC power supply
- One ACL-PCIEXT-2 cable
- One AC power cord
- This User's Manual

If any of these items are missing or damaged, contact your ADLINK dealer. Save the shipping materials and carton in to ship or store the product in the future.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.2 Unpacking

The ADLINK PCIS-8580 system contains some electro-static sensitive components that can be easily be damaged by static electricity. For this reason, the card and chassis should be handled on a grounded anti-static mat and the operator should wear an anti-static wristband during the unpacking and installation procedure.

Please also inspect the components for apparent damage. Improper shipping and handling may cause damage to the components. Be sure there are no shipping and handling damage on the components before continuing.

You are now ready to set up your PCIS-8580 PCI-to-PCI expansion system.

Note: DO NOT APPLY POWER TO THE CARD OR CHASSIS IF IT HAS BEEN DAMAGED.

2.3 Getting Start

In this section, we'll illustrate the step-by-step instructions to set up your PCIS-8580 PCI-to-PCI expansion system.

Install PCI Expansion Card into your Host System

The first step is to install the PCI expansion card (LPCI-8575) into your host system. You can find an individual carton in the whole package which contains the PCI expansion card. The steps of installation are:

1. Turn off your host computer.
2. Open the chassis of the host computer.
3. Remove the package of PCI expansion card. (Please wear your anti-static facilities when you handle the card.)
4. Plug the PCI expansion card into an available PCI slot and screw it to the chassis.
5. Close the chassis.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000




Figure 2-1: Install the PCI expansion card into your host system

Driver Installation

After installing the PCI expansion card into your host computer, now you can turn on your computer and install the driver of PCI expansion card. Please follow the following steps to finish the driver installation.

1. Insert the ADLINK ALL-In-One CD.
2. Execute x:\Driver Installation\PCI Expansion\PCIS_8580_setup.exe to launch the setup program. (x: denotes your CD-ROM drive). A InstallShield® wizard appears to guide you finish the setup procedure.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000




Figure 2-2: Installing the driver for PCI expansion card

3. While setup finishes, please reboot your system. (Note: According to different hardware configuration, you may need to reboot your computer for several times to detect the StarFabric serialized bridge and its subsequent PCI devices.)

Install your PCI Card into the Expansion Chassis

The PCIS-8580 expansion chassis can accommodate 4 additional PCI slots (PCIS-8580-4S) or 13 additional PCI slots (PCIS-8580-13S). This section illustrates the procedures to install your PCI cards into the expansion chassis.

1. Open the expansion chassis by loosen the screws and remove the top cover of the chassis. You'll see a back-plane inside the chassis.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2. Plug you PCI cards into the expansion chassis and screw them to the chassis.
3. Put the top cover and tighten the screws.




Figure 2-3: Install your PCI cards into the expansion chassis (using the PCIS-8580-4S as an example)

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Connect to Expansion Chassis

Your host computer and the expansion chassis are connected via a cable (ACL-PCIEXT-2). This cable uses the DVI-D connector and customized shielding twisted pairs to make a robust high-speed serial link. Please DO NOT use standard DVI cable to connect your host computer and the expansion chassis.




Figure 2-4: Connect you host computer and expansion chassis (using the PCIS-8580-4S as an example)

Power-on Sequence

To make the PCI-to-PCI expansion system works well, you need to follow a correct power-on sequence for both expansion chassis and host computer. The LINK indicators (a green LED) on the front-panel of the expansion chassis and LPCI-8575 indicate the status of serial link between the expansion chassis and the host computer. When the LINK LED is on, the link is good, otherwise when the LINK LED is off or blinking, the link is failed.

1. Make sure the cable is correctly connected and screw the connectos.
2. Turn on the expansion chassis.
3. Turn on the host computer. At this time you'll see the LINK indicators on both sides are on.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3 Hardware Overview

This chapter illustrates the basic hardware architecture of each component in the ADLINK PCIS-8580 PCI-to-PCI expansion system.

3.1 System Architecture

This section describes the operation theory and technology of the PCIS-8580 PCI-to-PCI expansion system.

Operation Theory




Figure 3-1: Operation theory of PCIS-8580 PCI-to-PCI expansion system

The PCIS-8580 PCI-to-PCI expansion system utilizes the state-of-art StarFabric technology as the groundwork for extending the PCI bus. A PCI-StarFabric bridge located on the host computer provides an interface between PCI and StarFabric port, which translates the parallel PCI signals into serial frame format for transmission across StarFabric link. Each StarFabric link contains 4 pairs, 622Mps LVDS signals and provides 2.5Gbps total bandwidth to accommodate complete PCI traffic without any compromise in bandwidth. Error detection and error correction are automatically performed during the StarFabric transmission to guarantee the data integrity.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2 LPCI-8575 PCI Expansion Card

This section describes the basic function, bus architecture and jumper settings of the PCI expansion module LPCI-8575.

Functional Block

The LPCI-8575 expansion module is basically a PCI-to-PCI bridge. The PCI-to-PCI bridge function in the LPCI-8575 supports legacy address routed traffic, which provides 100% capability with PCI drivers, application software, BIOS, O/Ss, etc. These functions allow users to transfer their designs without extra effort.

The LPCI-8575 employs a serial interconnect technology, 622Mbps low voltage differential signaling (LVDS). Each LPCI-8575 expansion module has one link port, the link port is divided into transmit (TX) and receive (RX). Four TX and RX differential pairs in the link are used to provide 2.5Gbps full duplex link bandwidth or 5Gbps of total bandwidth. Incorporated with the high speed serial LVDS, it is easy to extend the transmission up to 10 meters through shielded twisted pair copper cables.

Inside the PCI-to-PCI bridge, a PCI-to-StarFabric/StarFabric-to-PCI converter is used to translate PCI transactions into StarFabric frames and StarFabric frames into PCI transactions. The PCI interface of the LPCI-8575 is capable of 32-bit/66MHz. Thus the maximum data throughput can up to 264Mbytes/s. The PCI interface in LPCI-8575 acts like the primary side of a PCI-to-PCI bridge if LPCI-8575 is plugged into the peripheral slot.




Figure 3-2: Concept of the serialized PCI bridge

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Jumper Settings for LPCI-8575

The following figure shows the locations of jumpers and the connector.




Figure 3-3: Jumpers and connectors on the LPCI-8575

Jumper / Connector / LED	Descriptions
CN1	A DVI-D connector for the serial link for PCI-to-PCI expansion. *Please DO NOT connect CN1 to any monitor or video device.*
JP1	Spread spectrum control.
JP2	M66EN setting.
JP3	Peripheral / System slot selection.
JP4	Serial link status LED connector.
D2	Serial link status LED.

Table 3-1: Jumpers and connectors on the LPCI-8575

Spread Spectrum Control, JP1

When LPCI-8575 plugged into the expansion chassis, it provides a discrete clock signal to each of the peripheral slot defined as a PCI clock (CLK0, CLK1, CLK2 and CLK3).

An important feature of the LPCI-8575 expansion modules is that it support 33MHz/66MHz clock operating environment. As system clock increase, electromagnetic interference (EMI) becomes a challenge for the system designers. LPCI-8575

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

adopts a spread-spectrum clock generator to help user to deal with this difficult task.

Spread spectrum clocking speeds up and slows down the clock within a few percent of its fundamental frequency. By reducing the peak amplitudes, the system will more likely meet EMI emission compliance standards. In other words, spread spectrum clocking distributes the energy that was originally concentrated on one frequency over a wider band. This method dramatically reduces the amount of EMI.



Spread Spectrum Control	JP1
OFF (default)	
ON	

Table 3-2: JP1 Settings

M66EN Setting, JP2

LPCI-8575 supports 32-bit PCI buses operating at 66MHz or 33MHz. A bundled link can support the full bandwidth of 32-bit/ 66MHz PCI bus. You can utilize the following configuration to set the operation frequency of your system.


JP2	Setting
	Auto detection mode enabled. When LPCI-8575 is plugged into system slot in the extended chassis, it will detect the configuration and operate at 33MHz or 66MHz automatically. If the backplane or any devices in the system do not support 66MHz PCI bus operations, LPCI-8575 will only operate at 33 MHz only.

Table 3-3: JP2 Settings

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


JP2	Setting
 (Default)	Auto detection mode disabled, force to 33MHz. PCI bus is forced to operate at 33 MHz. If your extended system is 66MHz capable, please switch JP2 to 1-2 contact.

Table 3-3: JP2 Settings

Peripheral / System Slot Selection, JP3

LPCI-8575 is a dual purpose PCI-to-PCI expansion module. When LPCI-8575 plugged into a peripheral, it becomes a peripheral card. When LPCI-8575 plugged into the expansion chassis system slot, it becomes a system card.





JP3 Setting	Descriptions
 (Default)	Auto selection. LPCI-8575 will detect the slot configuration automatically.
	Force to Peripheral slot.
	Force to system slot.

Table 3-4: JP3 Settings

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Serial Link Status LED Connector, JP4

The serial link status is shown on LED D2. LPCI-8575 also provides a LED connector for user's applications. The pin assignment of JP4 is shown in the following figure.



Serial Link Status LED, D2

The LED D2 shows the serial link status. The following table shows the possible status of the LED when you turn on the expansion chassis power and main system power.

LED status	Descriptions	How to solve?
ON	The serial link is synchronous. The power on sequence is correct.	
Twinkling	The serial link is not synchronous. The main system power is turned on before expansion chassis power.	Reset the main system or re-boot the main system power after expansion chassis power is on.
OFF	The serial link connection is not correct.	Check if the serial link cable is ok or not.

Table 3-5: D2 Display

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.3 BP-8005

This section describes the architecture and jumper settings of the BP-8005 backplane. The BP-8005 is for PCIS-8580-4S and is pre-installed in the RK-8005 chassis.

Backplane Architecture

The BP-8005 backplane provides 1 system slot and 4 available PCI peripheral slots. The system slot is occupied by a pre-installed

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

LPCI-8575 PCI expansion card. The rest PCI slots are available for any 5V PCI peripheral cards.




Figure 3-4: Top view of BP-8005 backplane

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000




Figure 3-5: Bottom view of BP-8005 backplane

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Jumpers and Connectors

Jumpers and connectors on the top side

JP/CN	Ended	Voltage Out	Description
CN3	3	+12V, GND	Fan connector for 12V fan
JP1	2	+5V, GND	LED connector
JP3	2	+12V, GND	Fan connector for 12V fan

Table 3-6: Top side jumpers and connectors

Jumpers and connectors on the bottom side

JP/CN	Ended	Voltage Out	Description
CN1	2	5V, GND	LED connector
CN2	20	3.3V, ±12V, 5V	ATX POWER connector
CN4	2	5V, GND	POWER-OK status connector
JP2	2	N/A	ATX POWER ENABLE

Table 3-7: Bottom side jumpers and connectors

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.4 RK-8005

RK-8005 is a robust industrial chassis for accommodating the BP-8005 backplane. The RK-8005 is a small, compact chassis (122mm x 195mm x 260mm) with a built-in 200W universal AC power supply. The RK-8005 is provided with a wall-mount kit so you can place it in many different environments.

Mechanical Drawing of RK-8005




Figure 3-6: Mechanical drawing of RK-8005

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.5 BP-8014

This section describes the architecture and jumper settings of the BP-8014 backplane. The BP-8014 is for PCIS-8580-13S and is pre-installed in the RK-8014 chassis.

Backplane Architecture

The BP-8014 backplane provides 1 system slot and 13 available PCI peripheral slots. The system slot is occupied by a pre-installed LPCI-8575 PCI expansion card. The rest PCI slots are available for any 5V PCI peripheral cards.




Figure 3-7: Top view of BP-8014 backplane

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Jumpers and Connectors

JP/CN	Ended	Voltage Out	Description
CN2	20	3.3V,±12V,5V	ATX POWER connector
FAN4	3	12V, GND	Fan connector for 12V fan
FAN5	3	12V, GND	Fan connector for 12V fan
FAN6	3	12V, GND	Fan connector for 12V fan
JP2	2	N/A	ATX POWER ENABLE
JP6	2	5V, GND	POWER-OK status connector
JP7	2	5V, GND	LED connector

Table 3-8: BP-8014 jumpers and connectors

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.6 RK-8014

RK-8014 is a robust industrial chassis for accommodating the BP-8014 backplane. The RK-8014 is a 19” rack-mount chassis with a built-in 400W universal AC power supply.

Mechanical Drawing of RK-8014




Figure 3-8: Mechanical drawing of RK-8014

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.7 ACL-PCIEXT-2

ACL-PCIEXT-2 is the cable connecting the host computer and the expansion chassis. It is carefully designed to transmit 622Mbps LVDS signals. ACL-PCI-EXT-2 contains 8 pairs of shielding twisted copper wires and 2 DVI-D 24-pin connectors. For users who need longer expansion distance, optional ACL-PCIEXT-5 (5m) and ACL-PCIEXT-10 (10m) are provided.

Note: THE ACL-PCIEXT-2 CABLE IS USED FOR PCIS-8680 ONLY. DO NOT APPLY ACL-PCIEXT-2 TO ANY OTHER DEVICES TO AVOID UNEXPECTED DAMAGES.

Pin Assignment of ACL-PCIEXT-2




Figure 3-9: DVI Connector pins and dimensions

#1	#2	#3	#4	#5	#6	#7	#8
RX3+	RX3-	Shield	TX0+	TX0-	Shield	TX1+	TX1-
#9	**#10**	**#11**	**#12**	**#13**	**#14**	**#15**	**#16**
RX2+	RX2-	Shield	Shield	Shield	Shield	TX2+	TX2-
#17	**#18**	**#19**	**#20**	**#21**	**#22**	**#23**	**#24**
RX1+	RX1-	Shield	RX0+	RX0-	Shield	TX3+	TX3-

Table 3-9: Pin Assignment of ACL-PCIEXT-2

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000