MVP-6100 Series

High Performance
9th Generation Intel® Xeon®/Core™ i7/i5/i3 &
8th Gen Celeron® Processor-Based
Fanless Expandable Computer

MVP-6120/MVP-6140

User's Manual



Manual Rev.: 1.0

Revision Date: Jan 21, 2020

Part No: 50-1Z306-1000

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Leading **EDGE COMPUTING**

Revision History

Revision	Release Date	Description of Change(s)
1.0	Jan.21, 2020	Initial release

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Preface

Copyright © 2020 ADLINK Technology Inc.


This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Disclaimer

The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

Environmental Responsibility



ADLINK is committed to fulfill its social responsibility to global environmental preservation through compliance with the European Union's Restriction of Hazardous Substances (RoHS) directive and Waste Electrical and Electronic Equipment (WEEE) directive. Environmental protection is a top priority for ADLINK. We have enforced measures to ensure that our products, manufacturing processes, components, and raw materials have as little impact on the environment as possible. When products are at their end of life, our customers are encouraged to dispose of them in accordance with the product disposal and/or recovery programs prescribed by their nation or company.

Battery Labels (for products with battery)



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

California Proposition 65 Warning

WARNING: This product can expose you to chemicals including acrylamide, arsenic, benzene, cadmium, Tris(1,3-dichloro-2-propyl) phosphate (TDCPP), 1,4-Dioxane, formaldehyde, lead, DEHP, styrene, DINP, BBP, PVC, and vinyl materials, which are known to the State of California to cause cancer, and acrylamide, benzene, cadmium, lead, mercury, phthalates, toluene, DEHP, DIDP, DnHP, DBP, BBP, PVC, and vinyl materials, which are known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Trademarks

Product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

Conventions

Take note of the following conventions used throughout this manual to make sure that users perform certain tasks and instructions properly.

NOTE: Additional information, aids, and tips that help users perform tasks.

CAUTION: Information to prevent ***minor*** physical injury, component damage, data loss, and/or program corruption when trying to complete a task.
ATTENTION: Informations destinées à prévenir les blessures corporelles mineures, les dommages aux composants, la perte de données et/ou la corruption de programme lors de l'exécution d'une tâche.

WARNING: Information to prevent ***serious*** physical injury, component damage, data loss, and/or program corruption when trying to complete a specific task.
AVERTISSEMENT: Informations destinées à prévenir les blessures corporelles graves, les dommages aux composants, la perte de données et/ou la corruption de programme lors de l'exécution d'une tâche spécifique.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Table of Contents

Preface iii

List of Tables vii

List of Figures ix

1 Introduction 1
- 1.1 Overview 1
- 1.2 Features 1
- 1.3 Packing List 2
- 1.4 Optional Accessories 2

2 Specifications 3
- 2.1 MVP-612X/MVP-614X/MVP-612A/MVP-614A 3
- 2.2 MVP-6121/MVP-6141/MVP-6122/MVP-6142 5
- 2.3 MVP-6123/MVP-6143/MVP-6124/MVP-6144 7
- 2.4 MVP-6100 Functional Block Diagram 9
- 2.5 Display Options 10
- 2.6 Mechanical Dimensions 11

3 System Layout 17
- 3.1 Front Panel 17
- 3.2 Internal I/O Connectors 29

4 Getting Started 37
- 4.1 Attach DC Power Connector 37
- 4.2 Mounting the MVP-6100 38
- 4.3 Driver Installation 40

A Appendix: Power Consumption 41
- A.1 Power Consumption Reference 41

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B Appendix: BIOS Setup.....43
B.1 Main 44
B.2 Advanced 46
B.3 Chipset 63
B.4 Security 77
B.5 Boot 79
B.6 Save & Exit 81

C Appendix: Watchdog Timer (WDT) Function Library 83
C.1 WDT with API/Windows 83
C.2 WDT with DOS/Linux 86

D Appendix: Digital Input/Output Function Library 89

Important Safety Instructions..... 91

Consignes de Sécurité Importante 93

Getting Service 97

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

List of Tables

Table 2-1: Max. Available Resolution Display Configuration 10
Table 3-1: Front Panel I/O Legend 17
Table 3-2: LED Indicators 18
Table 3-3: DisplayPort Pin Definition 19
Table 3-4: Applicable Cable Types 19
Table 3-5: Digital Input/Output Connector Pin Definition 20
Table 3-6: DVI-D Connector Pin Definition 22
Table 3-7: VGA Connector Pin Definition 23
Table 3-8: Ethernet Port Pin Definition 25
Table 3-9: Active/Link LED Indicators 25
Table 3-10: Speed LED Indicators 25
Table 3-11: DC Power Input Pin Definition 26
Table 3-12: D-Sub 9-pin Signal Function of COM Ports 27
Table 3-13: Mainboard Connector Legend 30
Table 3-14: 2-slot Backplane Board Connector Legend 31
Table 3-15: 4-slot Backplane Board Connector Legend 32
Table 3-16: GPS Module Power Header Pin Definition 33
Table 3-17: 12V Fan Connector Pin Definition 34
Table 3-18: PWR/RESET Header Pin Definition 35
Table 3-19: 12V Power Pin Definition 35
Table A-1: Power Consumption 41

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

This page intentionally left blank.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

List of Figures

Figure 2-1: MVP-6120 Front View 11
Figure 2-2: MVP-6140 Front View 12
Figure 2-3: MVP-6120/6140 Left Side View 13
Figure 2-4: MVP-6120/6140 Right Side View 14
Figure 2-5: MVP-6120/6140 Top View (incl. wall-mount brackets) 15
Figure 3-1: Front Panel I/O 17
Figure 3-2: DisplayPort Connector Pin Definition 19
Figure 3-3: Digital I/O Connector Pin Definition 20
Figure 3-4: Digital Input Circuit 21
Figure 3-5: Digital Output Circuit 21
Figure 3-6: DVI-D Connector Pin Definition 22
Figure 3-7: VGA Connector Pin Definition 23
Figure 3-8: Ethernet Port and LEDs 25
Figure 3-9: DC Power Input 26
Figure 3-10: COM Port Pin Definition 27
Figure 3-11: CFast Host Slot 28
Figure 3-12: Mainboard Connectors 29
Figure 3-13: 2-slot Backplane Board Connectors 31
Figure 3-14: 4-slot Backplane Board Connectors 32
Figure 3-15: GPS Module Power Header Pin Definition 33
Figure 3-16: 12V Fan Connector Pin Definition 34
Figure 3-17: Clear CMOS Jumper Setting 34
Figure 3-18: PWR/RESET Header Pin Definition 35
Figure 3-19: 12V Power Pin Definition 35

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

This page intentionally left blank.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1 Introduction

1.1 Overview

ADLINK's MVP-6100 Series of value line fanless embedded computing platforms, incorporating Intel® Core™/Xeon®/Celeron® processors, provides one PCIe x16 and one PCI slot, one mini-PCIe slot and single-side access for I/O ports, optimizing easy maintenance in industrial automation environments. The series retains the robust design of all ADLINK MXC/MXE lines, at a new extremely cost-effective price point. The MVP-6100 series supports DDR4 memory for more powerful computing and the Intel® HD Graphics 630 speeds graphics performance. Along with a versatile I/O array and flexible expansion capacity, the MVP-6100 Series fully satisfies all the needs of industrial automation (IA) with the performance demanded by vision inspection, motion control, and surveillance applications. Fanless construction not only overcomes contaminant and noise challenges presented by harsh IA environments, the elimination of problematic structural elements that negatively affect MTBF greatly increases lifecycle expectations for the platform.

1.2 Features

- 9th Generation Intel® Core™/Xeon™ i7/i5/i3 FCLGA1151 processor + C246/H310 chipset
- 2 x DDR4 SO-DIMM socket, supporting up to 32GB DDR4 2400 SO-DIMM Module
- MVP-6120 Series: 1x PCIe x16 + 1x PCI, MVP-6140 Series: 1x PCIe x16 + 2x PCIe x4 + 1x PCI, with both PCIe x16 supporting Gen3 PCIe cards
- 2x DisplayPort, 1x DVI-D and 1x VGA, supporting 2 independent displays w/ H310; 3 independent displays w/ C246
- 6 External USB ports (3x USB 3.0, 3x USB 2.0), 1 internal USB 2.0 port
- 3 Intel GbE LAN ports with teaming function

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

- Built-in 8CH DI and 8CH DO, 2 software-programmable RS-232/422/485 + 2 RS-232 ports
- CFast socket, onboard SATA 6Gb/s port for 2.5” HDD/SSD installation, and SATA 6Gb/s
- Built-in wide-range 12V DC to 24V DC power input

1.3 Packing List

Before unpacking, check the shipping carton for any damage. If the shipping carton and/or contents are damaged, inform your dealer immediately. Retain the shipping carton and packing materials for inspection. Obtain authorization from your dealer before returning any product to ADLINK. Ensure that the following items are included in the package.

- MVP-6100 Fanless Embedded Computer
- Accessory Box
  - DC power jack
  - Wall-mount brackets
  - Screw pack

1.4 Optional Accessories

- AC/DC Adapter
  - 220W (P/N: 31-62149-0000)
  - 280W (P/N: 91-95263-0010)

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2 Specifications

2.1 MVP-612X/MVP-614X/MVP-612A/MVP-614A

	MVP-612X	MVP-614X	MVP-612A	MVP-614A
System Core				
Processor	Intel® Xeon® 80W		Intel® Core™ i7 65W	
Chipset	C246		H310	C246
Memory	4GB DDR4 2400MHz, dual SODIMMs, up to 32GB Optional: 8/16/32GB DDR4 ECC 2400MHz			
I/O Interface				
Display	2x DP++, DVI-D, VGA (3 displays)			
Expansion Slots	PCIe x16 + PCI	PCIe x16 + 2 PCIe x4 + PCI	PCIe x16 + PCI	PCIe x16 + 2 PCIe x4 + PCI
Ethernet	3x Intel GbE: 2x i211AT + i219 iAMT support			
Serial Ports	COM1/2: RS-232/422/485 COM3/4: RS-232 Optional: COM5/6 RS-232 (shared w/ DI/O)			
USB	2x USB 3.1 Gen2, 1x USB 3.1 Gen1, 3x USB 2.0, 1x internal USB 2.0 dongle		3x USB 3.1 Gen 1 + 3x USB 2.0 + 1x internal USB 2.0 dongle	2x USB 3.1 Gen2, 1x USB 3.1 Gen1, 3x USB 2.0, 1x internal USB 2.0 dongle
Audio	Line-out, Mic-in (optional: speaker-out)			
Mini PCIe	1x Full size (USB 2.0 + PCIe)			
M.2	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x2		1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x1	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x2
USIM	2			
DI/O	8-ch DI and 8-ch DO			
I2C	2 (3.3V/5V)			
TPM 2.0	Yes			
Storage				
2.5" SATA	2 (extra 2 w/ optional kit w/ C246, supports RAID 0/1/5/10)			
CFast	1 Type II			

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

	MVP-612X	MVP-614X	MVP-612A	MVP-614A
Physical				
Dimensions	165 (W) x 240 (D) x 210 (H) mm (6.5" x 9.45" x 8.27")	206 (W) x 240 (D) x 210 (H) mm (8.11" x 9.45" x 8.27")	165 (W) x 240 (D) x 210 (H) mm (6.5" x 9.45" x 8.27")	206 (W) x 240 (D) x 210 (H) mm (8.11" x 9.45" x 8.27")
Weight	4.8 kg (10.6 lb.)	5.1 kg (11.2 lb.)	4.8 kg (10.6 lb.)	5.1 kg (11.2 lb.)
Mounting	Wall mount			
Power Supply				
DC Input	12-24VDC (± 10% tolerance)			
AC Input	Optional: 220W/280W AC/DC adapter			
Environmental				
Operating Temperature	0°C to 40°C w/ airflow 0.6 m/s		0°C to 50°C w/ airflow 0.6 m/s	
	Extended Temperature (w/ Ind. storage), w/ airflow 0.6 m/s			
	-20°C to 40°C		-20°C to 50°C	
Storage Temperature	-40°C to 85°C (-40°F to 185°F)			
Humidity	approx. 95% @ 40°C (non-condensing)			
Vibration	Operating: 5 Grms, 5-500 Hz, 3 axes (w/2.5" SSD/CFast) Operating: 0.3 Grms, 5-500 Hz, 3 axes (w/ HDD)			
Shock	Operating: 50 Grms, half sine 11ms duration (w/ 2.5" SSD/CFast)			
ESD	Contact +/-4kV, Air +/-8kV			
EMC	EN61000-6-4/-2, CE & FCC Class A			
Safety	UL/cUL, CB, CCC			

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.2 MVP-6121/MVP-6141/MVP-6122/MVP-6142

	MVP-6121	MVP-6141	MVP-6122	MVP-6142
System Core				
Processor	Intel® Core™ i7 35W		Intel® Core™ i5 35W	
Chipset	H310	C246	H310	C246
Memory	4GB DDR4 2400MHz, dual SODIMMs, up to 32GB Optional: 8/16/32GB DDR4 ECC 2400MHz (only for Intel® Xeon®/Core™ i3/Celeron® w/ C246)			
I/O Interface				
Display	2x DP++, DVI-D, VGA (dual displays)	2x DP++, DVI-D, VGA (3 displays)	2x DP++, DVI-D, VGA (dual displays)	2x DP++, DVI-D, VGA (3 displays)
Expansion Slots	PCIe x16 + PCI	PCIe x16 + 2 PCIe x4 + PCI	PCIe x16 + PCI	PCIe x16 + 2 PCIe x4 + PCI
Ethernet	3x Intel GbE: 2x i211AT +i219 support	3x Intel GbE: 2x i211AT + i219, iAMT support	3x Intel GbE: 2x i211AT +i219 support	3x Intel GbE: 2x i211AT + i219, iAMT support
Serial Ports	COM1/2: RS-232/422/485, COM3/4: RS-232 Optional: COM5/6 RS-232 (shared w/ DI/O)			
USB	3x USB 3.1 Gen 1 + 3x USB 2.0 + 1x internal USB 2.0 dongle	2x USB 3.1 Gen2, 1x USB 3.1 Gen1, 3x USB 2.0, 1x internal USB 2.0 dongle	3x USB 3.1 Gen 1 + 3x USB 2.0 + 1x internal USB 2.0 dongle	2x USB 3.1 Gen2, 1x USB 3.1 Gen1, 3x USB 2.0, 1x internal USB 2.0 dongle
Audio	Line-out, Mic-in (optional: speaker-out)			
Mini PCIe	1x Full size (USB 2.0 + PCIe)			
M.2	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x1	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x2	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x1	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x2
USIM	2			
DI/O	8-ch DI and 8-ch DO			
I2C	2 (3.3V/5V)			
TPM 2.0	Yes			

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

	MVP-6121	MVP-6141	MVP-6122	MVP-6142
Storage				
2.5" SATA	2 (extra 2 w/ optional kit w/ C246, supports RAID 0/1/5/10)			
CFast	1 Type II			
Physical				
Dimensions	165 (W) x 240 (D) x 210 (H) mm (6.5" x 9.45" x 8.27")	206 (W) x 240 (D) x 210 (H) mm (8.11" x 9.45" x 8.27")	165 (W) x 240 (D) x 210 (H) mm (6.5" x 9.45" x 8.27")	206 (W) x 240 (D) x 210 (H) mm (8.11" x 9.45" x 8.27")
Weight	4.8 kg (10.6 lb.)	5.1 kg (11.2 lb.)	4.8 kg (10.6 lb.)	5.1 kg (11.2 lb.)
Mounting	Wall mount			
Power Supply				
DC Input	12-24VDC (± 10% tolerance)			
AC Input	Optional: 220W/280W AC/DC adapter			
Environmental				
Operating Temperature	Standard: 0°C to 50°C, w/ airflow 0.6 m/s			
	Extended Temperature (w/ Ind. storage), w/ airflow 0.6 m/s			
	-20°C to 60°C			
Storage Temperature	-40°C to 85°C (-40°F to 185°F)			
Humidity	approx. 95% @ 40°C (non-condensing)			
Vibration	Operating: 5 Grms, 5-500 Hz, 3 axes (w/2.5" SSD/CFast) Operating: 0.3 Grms, 5-500 Hz, 3 axes (w/ HDD)			
Shock	Operating: 50 Grms, half sine 11ms duration (w/ 2.5" SSD/CFast)			
ESD	Contact +/-4kV, Air +/-8kV			
EMC	EN61000-6-4/-2, CE & FCC Class A			
Safety	UL/cUL, CB, CCC			

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.3 MVP-6123/MVP-6143/MVP-6124/MVP-6144


	MVP-6123	MVP-6143	MVP-6124	MVP-6144
System Core				
Processor	Intel® Core™ i3 35W		Intel® Celeron® 35W	
Chipset	H310	C246	H310	C246
Memory	4GB DDR4 2400MHz, dual SODIMMs, up to 32GB Optional: 8/16/32GB DDR4 ECC 2400MHz (only for Intel® Xeon®/Core™ i3/Celeron® w/ C246)			
I/O Interface				
Display	2x DP++, DVI-D, VGA (dual displays)	2x DP++, DVI-D, VGA (3 displays)	2x DP++, DVI-D, VGA (dual displays)	2x DP++, DVI-D, VGA (3 displays)
Expansion Slots	PCIe x16 +, PCI	PCIe x16 + 2, PCIe x4 +, PCI	PCIe x16 +, PCI	PCIe x16 + 2, PCIe x4 +, PCI
Ethernet	3x Intel GbE: 2x i211AT+ i219 support	3x Intel GbE: 2x i211AT + i219, iAMT support	3x Intel GbE: 2x i211AT+ i219 support	3x Intel GbE: 2x i211AT + i219, iAMT support
Serial Ports	COM1/2: RS-232/422/485, COM3/4: RS-232 Optional: COM5/6 RS-232 (shared w/ DI/O)			
USB	3x USB 3.1 Gen 1 + 3x USB 2.0, 1x internal USB 2.0 dongle	2x USB 3.1 Gen2 + 1x USB 3.1 Gen1 + 3x USB 2.0, 1x internal USB 2.0 dongle	3x USB 3.1 Gen 1 + 3x USB 2.0, 1x internal USB 2.0 dongle	2x USB 3.1 Gen2 + 1x USB 3.1 Gen1 + 3x USB 2.0, 1x internal USB 2.0 dongle
Audio	Line-out, Mic-in (optional: speaker-out)			
Mini PCIe	1x Full size (USB 2.0 + PCIe)			
M.2	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x1	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x1 up to PCIe x2	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x1	1x 2280/3042: USB 3.1, SATA 6Gb/s and PCIe x1 up to PCIe x2
USIM	2			
DI/O	8-ch DI and 8-ch DO			
I2C	2 (3.3V/5V)			
TPM 2.0	Yes			

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

	MVP-6123	MVP-6143	MVP-6124	MVP-6144
Storage				
2.5" SATA	2 (extra 2 w/ optional kit w/ C246, supports RAID 0/1/5/10)			
CFast	1 Type II			
Physical				
Dimensions	165 (W) x 240 (D) x 210 (H) mm (6.5" x 9.45" x 8.27")	206 (W) x 240 (D) x 210 (H) mm (8.11" x 9.45" x 8.27")	165 (W) x 240 (D) x 210 (H) mm (6.5" x 9.45" x 8.27")	206 (W) x 240 (D) x 210 (H) mm (8.11" x 9.45" x 8.27")
Weight	4.8 kg (10.6 lb.)	5.1 kg (11.2 lb.)	4.8 kg (10.6 lb.)	5.1 kg (11.2 lb.)
Mounting	Wall mount			
Power Supply				
DC Input	12-24VDC (± 10% tolerance)			
AC Input	Optional: 220W/280W AC/DC adapter			
Environmental				
Operating Temperature	Standard: 0°C to 50°C, w/ airflow 0.6 m/s			
	Extended Temperature (w/ Ind. storage), w/ airflow 0.6 m/s			
	-20°C to 60°C			
Storage Temperature	-40°C to 85°C (-40°F to 185°F)			
Humidity	approx. 95% @ 40°C (non-condensing)			
Vibration	Operating: 5 Grms, 5-500 Hz, 3 axes (w/2.5" SSD/CFast) Operating: 0.3 Grms, 5-500 Hz, 3 axes (w/ HDD)			
Shock	Operating: 50 Grms, half sine 11ms duration (w/ 2.5" SSD/ CFast)			
ESD	Contact +/-4kV, Air +/-8kV			
EMC	EN61000-6-4/-2, CE & FCC Class A			
Safety	UL/cUL, CB, CCC			

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.4 MVP-6100 Functional Block Diagram



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.5 Display Options

With computing and graphic performance enhancement from its 8th & 9th Generation Intel processors, the MVP-6100 controller can support two (H310) or three (C246) independent displays, with configurations as follows.

	Port	Resolution
Display Option 1	DisplayPort1	4096x2304@60Hz
Display Option 2	DisplayPort2	4096x2304@60Hz
Display Option 3	DVI-D	1920x1200@60Hz
Display Option 4	VGA	1920x1080@60Hz

Table 2-1: Maximum Available Resolution Display Configurations

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.6 Mechanical Dimensions




Figure 2-1: MVP-6120 Front View





Figure 2-2: MVP-6140 Front View



units: mm

Figure 2-3: MVP-6120/6140 Left Side View




Figure 2-4: MVP-6120/6140 Right Side View

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000




Figure 2-5: MVP-6120/6140 Top View (including wall-mount brackets)

This page intentionally left blank.

3 System Layout

3.1 Front Panel

The MVP 6100 Series provides the following front panel access features.




Figure 3-1: Front Panel I/O

A	DC Power Input	**I**	Extend Power Button
B	DisplayPort x2	**J**	Power
C	DVI-D	**K**	Reset
D	VGA	**L**	Audio (Mic, Phones/Speaker)
E	USB 2.0 Type-A x3 (1, 2, 4)	**M**	Digital Input/Output
F	Gigabit Ethernet x 3	**N**	CFast
G	USB 3.1 Type-A x3 (3, 5, 6)	**O**	COM Port x4
H	LED Indicators		

Table 3-1: Front Panel I/O Legend

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.1.1 Power Button

The power button is a non-latched push button with a blue LED indicator. System is turned on when the button is depressed, and the power LED lights. If the system hangs, depress the button for 5 seconds to turn off the system completely.

3.1.2 LED Indicators

In addition to the LED of the power button, three LEDs on the front panel indicate the following.

LED Indicator	Color	Description
Watchdog (WD)	Yellow	Indicates watchdog timer status. When watchdog timer starts, the LED flashes. When the timer is expired, the LED remains lit..
Hard disk drive (HD)	Orange	Indicates the HDD operating state. When the SATA hard drive or CFast card is active, the LED indicator flashes.
Diagnostic (DG)	Green	When lit continuously, indicates no physical storage is connected, and if blinking, indicates no memory is installed on either SODIMM socket.

Table 3-2: LED Indicators

3.1.3 PCI Slot

The MVP-6100 provides one PCI slot for expansion on the back-plane board. Based on the ITE IT8892E PCIe to PCI bridge, connection to the host system is achieved through a PCIe x1 Gen3 interface, supporting universal or 5V PCI 32-bit cards operating at 33MHz clocks.

3.1.4 PCI Express x16 Slot

One PCI express x16 slot supports expansion with standard PCIe Gen3 cards and full PCI express x16 signals.

3.1.5 PCI Express x4 Slot

Two PCI Express x4 slots for MVP-6140 Series support expansion with standard PCIe Gen3 cards and full PCI express x4 signals.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.1.6 Reset Button

The reset button executes a hard reset for the MVP-6100.

3.1.7 DisplayPort Connectors

Two DisplayPort connectors on the front panel can connect to VGA, DVI, HDMI and DisplayPort monitors via DisplayPort to VGA adapter cable, DisplayPort to DVI adapter cable, or DisplayPort to HDMI adapter cable and DisplayPort cable.




Figure 3-2: DisplayPort Connector Pin Definition

Pin	Signal	Pin	Signal
1	CN_DDPx0+	11	GND
2	GND	12	CN_DDPx3-
3	CN_DDPx0-	13	CN_DDPx_AUX_SEL
4	CN_DDPx1+	14	CN_DDPx_CONFIG2
5	GND	15	CN_DDPx_AUX+
6	CN_DDPx1-	16	GND
7	CN_DDPx2+	17	CN_DDPx_AUX-
8	GND	18	CN_DDPx_HPD
9	CN_DDPx2-	19	GND
10	CN_DDPx3+	20	+V3.3_DDPx_PWR_CN

Table 3-3: DisplayPort Pin Definition

P/N	Description
30-01119-0020	Passive DisplayPort to HDMI adapter cable
30-01120-0020	Passive DisplayPort to DVI adapter cable
30-01121-0020	Passive DisplayPort to VGA adapter cable
30-01157-0020	Active DisplayPort to DVI adapter cable

Table 3-4: Applicable Cable Types

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.1.8 Digital I/O Connector

The MVP-6100 provides 8 channels of non-isolation digital input and 8 channels of non-isolation digital output circuits, with spec and circuits as follows.

8-channel Digital Input

- VIH: 2 to 5.25V
- VIL: 0 to 0.8V

8-channel Digital Output

- Output type: Open drain N-channel
- MOSFET driver with internal pull high of 200Ω resistance.
- Source/Sink current for all channels: 24mA
- VOH: 2.4 to 5V
- VOL: 0 to 0.5V




Figure 3-3: Digital I/O Connector Pin Definition

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	DI0	8	DI7	15	N/C	22	DO3
2	DI1	9	GND	16	N/C	23	DO4
3	DI2	10	N/C	17	N/C	24	DO5
4	DI3	11	N/C	18	GND	25	DO6
5	DI4	12	N/C	19	DO0	26	DO7
6	DI5	13	N/C	20	DO1		
7	DI6	14	N/C	21	DO2		

Table 3-5: Digital Input/Output Connector Pin Definition

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000




Figure 3-4: Digital Input Circuit




Figure 3-5: Digital Output Circuit

3.1.9 DVI-D Connector

The MVP-6100 provides one DVI-D connector for connection to an external monitor.




Figure 3-6: DVI-D Connector Pin Definition

Pin	Signal	Pin	Signal	Pin	Signal
1	DVIdata 2-	9	DVIdata 1-	17	DVIdata 0-
2	DVIdata 2+	10	DVIdata 1+	18	DVIdata 0+
3	GND	11	GND	19	GND
4	N/C	12	N/C	20	N/C
5	N/C	13	N/C	21	N/C
6	DVIDC clock	14	+5V	22	GND
7	DVIDC data	15	GND	23	DVI clock +
8	N/C	16	Hot plug detect	24	DVI clock -

Table 3-6: DVI-D Connector Pin Definition

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.1.10 VGA Connector




Figure 3-7: VGA Connector Pin Definition

Pin	Signal
1	G_VGA_R
2	G_VGA_G
3	G_VGA_B
4	N/C
5	GND
6	GND
7	GND
8	GND
9	N/C
10	GND
11	N/C
12	CRT_DDAT_CN
13	G_VGA_HSYNC
14	G_VGA_VSYNC
15	CRT_DCLK_CN

Table 3-7: VGA Connector Pin Definition

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.1.11 USB 2.0 Ports

The MVP-6100 provides three USB 2.0 ports supporting Type A USB connection on the front panel. All USB ports are compatible with high-speed, full-speed and low-speed USB devices. The MVP-6100 supports multiple boot devices, including USB flash drive, USB external hard drive, USB floppy, USB CD-ROM and others. The boot priority and boot device can be configured in BIOS.

3.1.12 USB 3.1 Ports

The MVP-6100 provides two USB 3.1 Gen2 and one USB 3.1 Gen1 ports supporting Type A USB 3.1 connection on the front panel. All USB 3.1 ports are compatible with SuperSpeed Gen2, high-speed, full-speed, and low-speed USB devices. The H310 SKU supports three USB 3.1 Gen1 ports only.

3.1.13 Gigabit Ethernet Ports

Three Gigabit Ethernet ports on the front panel support Intel WGI211AT and WGI219 Gigabit Ethernet PHY controller and connection, providing

- IEEE 802.3az Energy Efficient Ethernet
- IEEE 1588/802.1AS precision time synchronization
- IEEE 802.3Qav traffic shaper
- Interrupt moderation, VLAN support, IP checksum offload
- RSS and MSI-X to lower CPU utilization in multi-core systems
- ECC - error correcting memory in packet buffers
- Wake-On-LAN
- Preboot eXecution Environment (PXE) flash interface
- Jumbo frame support

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Speed LED Green/Orange	Active/Link Yellow




Figure 3-8: Ethernet Port and LEDs

Pin #	10BASE-T/ 100BASE-TX	1000BASE-T
1	TX+	LAN_TX0+
2	TX-	LAN_TX0-
3	RX+	LAN_TX1+
4	—	LAN_TX2+
5	—	LAN_TX2-
6	RX-	LAN_TX1-
7	—	LAN_TX3+
8	—	LAN_TX3-

Table 3-8: Ethernet Port Pin Definition

LED Color	Status	Description
Yellow	OFF	Ethernet port is disconnected.
	ON	Ethernet port is connected with no activity.
	Flashing	Ethernet port is connected and active.

Table 3-9: Active/Link LED Indicators

LED Color	Status	Description
Green/Orange	OFF	10 Mbps
	Green	100 Mbps
	Orange	1000 Mbps

Table 3-10: Speed LED Indicators

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.1.14 DC Power Input




Figure 3-9: DC Power Input

Pin	Signal
1	V+ (DC_IN)
2	V- (DGND)

Table 3-11: DC Power Input Pin Definition

Refer to Section 4.1: Attach DC Power Connector on page 37 to install the DC Power Connector to the DC Power Input.

Please use an approved power source as certified by IEC or UL. The maximum ambient operating temperature (Tma) is described in “Important Safety Instructions”. Altitude during operation is up to 2000 m where output meets LPS and SELV circuit requirements.

Power Source Rating

	Voltage	Current
DC Power Source	12 to 24VDC	21A to 10.5A min.
AC-to-DC Adapter	24VDC	10.5A min.

WARNING:

Before providing DC power, ensure the voltage and polarity provided are compatible with the DC input. Improper input voltage and/or polarity can be responsible for system damage.
AVERTISSEMENT: Avant de fournir une alimentation CC, assurez-vous que la tension et la polarité fournies sont compatibles avec l'entrée CC. Une tension d'entrée et / ou une polarité incorrectes peuvent être responsables de dommages au système.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.1.15 COM Port Connectors

The MVP-6100 provides four COM ports through D-sub 9-pin connectors. The COM1 & COM2 ports support RS-232/422/485 modes by BIOS setting, while COM3 and COM4 support only RS-232.




Figure 3-10: COM Port Pin Definition

Pin	Signal Name		
	RS-232	RS-422	RS-485
1	DCD#	TXD422-	485DATA-
2	RXD	TXD422+	485DATA+
3	TXD	RXD422+	N/S
4	DTR#	RXD422-	N/S
5	GND	N/S	N/S
6	DSR#	N/S	N/S
7	RTS#	N/S	N/S
8	CTS#	N/S	N/S
9	RI#	N/S	N/S

Table 3-12: D-Sub 9-pin Signal Function of COM Ports

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.1.16 CFast Host Slot

The MVP-6100 is equipped with a Type II Push-Push CFast host slot on the front panel, by SATA interface. Data transfer rates up to 3.0Gb/s (300MB/s) are supported. The host SATA controller provides a legacy operating mode using I/O space, and an AHCI operating mode using memory space. The CFast card can function as a storage device for system installation.

To install a CFast card, remove the 2 screws securing the cover to the chassis and remove the cover. Install the card and replace the cover using the 2 screws




Figure 3-11: CFast Host Slot

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2 Internal I/O Connectors

3.2.1 Mainboard Connector Locations




Figure 3-12: Mainboard Connectors

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

A	Smart Fan
B	SATA
C	USB 2.0 dongle
D	SATA
E	DDR4 SODIMM
F	PCIe x16 slot for PEG and SATA
G	M.2
H	Wafer for GPS external power
I	SIM for M.2
J	SIM for Mini PCIe
K	Mini PCIe
L	Wafer for I2C sensor
M	Wafer for Speaker
N	Wafer for COM x2, DI x8, DO x8 Mic in and Line out
O	Wafer for COM x4
P	Wafer for I2C sensor
Q	Internal Power button
R	PCIe x16 slot for PCIe and BP Power
S	RTC battery
T	Board-to-Board for AFM Board
U	CFast
V	PWR for AFM MXM carrier board (12V)
W	Clear CMOS Jumper

Table 3-13: Mainboard Connector Legend

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.2 2-slot Backplane Connector Locations

MVP-612X, MVP-612A, MVP-6121, MVP-6122, MVP-6123, MVP-6124



Figure 3-13: 2-slot Backplane Board Connectors

A	USB 2.0 dongle connector
B	SATA power connector
C	SATA signal connector
D	PCI slot
E	PCI express x16 slot
F	Additional power for PCIe x16 slot (12V)
G	Direct SATA connector

Table 3-14: 2-slot Backplane Board Connector Legend

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.3 4-slot Backplane Connector Locations

MVP-614X, MVP-614A, MVP-6141, MVP-6142, MVP-6143, MVP-6144




Figure 3-14: 4-slot Backplane Board Connectors

A	SATA power
B	SATA signal
C	Additional power for PCIe slot (12V)
D	USB 2.0 dongle
E	Fan
F	Direct SATA
G	PCI slot
H	PCIe x4 slot
I	PCIe x16 slot

Table 3-15: 4-slot Backplane Board Connector Legend

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.4 GPS Module Power Headers

Power supply via cable for Mini PCIe GPS module cards (5V).




Figure 3-15: GPS Module Power Header Pin Definition

Pin	Signal
1	+5V_GPS
2	GND

Table 3-16: GPS Module Power Header Pin Definition

3.2.5 USB 2.0 Connector

One USB 2.0 Type-A connector is provided on the mainboard for internal USB dongle, with another on the backplane board.

3.2.6 Mini PCIe Connector

The internal Mini PCIe connector (Rev. 1.2) supports full size Mini PCIe cards.

3.2.7 SATA Connector

The SATA connector supports transfer up to 6.0Gb/s (600MB/s).

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.8 12V Fan Connector

DC 12V fan module power supply is provided through the connector, to which the optional fan module connects when installed in the chassis.




Figure 3-16: 12V Fan Connector Pin Definition

Pin	Signal
1	FAN_GND
2	P_+12V_FAN
3	SIO_FAN_IN
4	SIO_FAN_OUT

Table 3-17: 12V Fan Connector Pin Definition

3.2.9 Clear CMOS Jumper

Upon encountering an abnormal condition preventing the MVP-6100 from booting, the jumper can clear the BIOS content stored in CMOS and restore default settings. To clear CMOS, short pin #1 to pin #2 for a minimum of 3 seconds, and then remove the jumper to return to normal mode (replace to pins #2 and #3, default).



Figure 3-17: Clear CMOS Jumper Setting

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.10 Extended PWR/RESET Header

An internal header is provided for the Power and Reset buttons, with pin definition as shown.




Figure 3-18: PWR/RESET Header Pin Definition

Pin	Signal
1	PWR_BTN-L
2	GND
3	GND
4	RESET_BTN-L

Table 3-18: PWR/RESET Header Pin Definition

3.2.11 USIM Slot

The USIM slot connects to the Mini PCIe and M.2 slots.

3.2.12 12V Power for Additional AFM MXM Carrier Board

One 12V power pin header provides additional AFM MXM carrier board power for an MXM card, if used.




Figure 3-19: 12V Power Pin Definition

Pin	Signal	Pin	Signal
1	P_+12V_B	3	GND
2	P_+12V_B	4	GND

Table 3-19: 12V Power Pin Definition

NOTE:

For additional information regarding the AFM MXM Carrier Board, please contact your ADLINK representative.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

This page intentionally left blank.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

4 Getting Started

4.1 Attach DC Power Connector

Locate the DC power connector shown below that is included in the Accessory Box. Insert it into the DC Power Input “A” shown in **Figure 3-1** on page 17 and secure it to the chassis using the captive screws.



Connect a DC power source as described in **Section 3.1.14: DC Power Input on page 26** to the inputs of the DC power connector, making sure to use the correct input voltage andpolarity.

WARNING:

Before providing DC power, ensure the voltage and polarity provided are compatible with the DC input. Improper input voltage and/or polarity can be responsible for system damage.
AVERTISSEMENT: Avant de connecter à une source de courant continu, veuillez vous assurer de la polarité de la tension conformément à l'entrée CC du PC. Une tension et/ou une polarité incorrectes peuvent causer des dommages irréversibles sur le système.


LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

4.2 Mounting the MVP-6100

4.2.1 Install the Wall-mount Brackets

Use the 6 M4 6mm screws included in the Accessory Box to attach the 2 included wall-mount brackets to the chassis as indicated by the red circles below.

Utilisez les 6 vis M4 6 mm incluses dans la boîte d'accessoires pour fixer les 2 supports de montage mural inclus au châssis, comme indiqué par les cercles rouges ci-dessous.




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Mounting the Device / Montage de l'Appareil

Mount the device to a wall using the 4 keyhole openings indicated or the 6 mounting holes circled in red, according to the spacing dimensions of the holes in the bracket as shown in Figure 2-1 MVP-6120 Front View and Figure 2-2 MVP-6140 Front View.

Montez l'appareil sur un mur à l'aide des 4 ouvertures de trou de serrure en fonction des dimensions d'espacement des trous dans le support, comme indiqué dans Figure 2-1 MVP-6120 Front View et Figure 2-2 MVP-6140 Front View.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

4.3 Driver Installation

Download the Windows 10 drivers for your system from the product page at https://www.adlinktech.com/Products/Industrial_PCs_Fanless_Embedded_PCs/ExpandableFanlessEmbeddedComputers/MVP-6100_Series and install.

The following drivers must be installed:

- Chipset
- Graphics
- Audio
- Ethernet
- Intel ME
- DI/O

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Appendix A Power Consumption

NOTE: Information in this Appendix is for power budget planning and design purposes only. Actual power consumption may differ based on final application.

A.1 Power Consumption Reference

Power consumption as follows is based on lab data in which 24V DC is applied and current is measured by the DC power supply. The power consumption (W) is calculated as the product of applied voltage (V) and the current (A).

Platforms tested for this data have available external I/O interfaces, and are attached to supported devices such as VGA and DVI monitors, CFast card, PS2 keyboard/mouse, USB dummy load, COM loopback, and audio loopback, and an internal hard disk driver is installed.

Information is presented for reference only. Actual power consumption will vary with different attached devices and operating system.

System	Power Off	System Idle	Processor Full Load	System Full Load	Recommended Power Supply
MVP-610X Intel® Xeon® 80W	4W	24W	130W	160W	220 or 280W
MVP-610A Intel® Core™ i7 65W	3.7W	21W	127W	144W	220 or 280W
MVP-6101 Intel® Core™ i7	3.6W	24W	65W	97W	220 or 280W
MVP-6102 Intel® Core™ i5	3.7W	22W	64W	94W	220 or 280W
MVP-6103 Intel® Core™ i3	3.8W	22W	56W	85W	220 or 280W
MVP-6104 Celeron®	4W	20W	41W	69W	220 or 280W

Table A-1: Power Consumption

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000



NOTE:

- Sufficient power supply for the entire system is required to meet these specifications. At least 100W at 24V input is recommended.
- Heat generated by add-on PCI/PCIe adapters affects thermal stability. Additional heat dissipation is required when the system operates at high temperatures or in harsh environments with add-on adapters.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Appendix B BIOS Setup

The Basic Input/Output System (BIOS) is a program that provides a basic level of communication between the processor and peripherals. In addition, the BIOS also contains codes for various advanced features applied to the MVP-6100. The BIOS setup program includes menus for configuring settings and enabling features of the MVP-6100. Most users do not need to use the BIOS setup program, as the MVP-6100 ships with default settings that work well for most configurations.


Enter BIOS setup by selecting DEL when the system is powered on the POST (Power On Self Test) message is displayed.The MVP-6100 controller supports one-time Boot Menu allowing selection of boot device. Enter the Boot Menu by selecting F7 at POST.


NOTE:

- BIOS options listed are for reference only.
- Different configurations can affect BIOS behavior.
- Displayed material may reflect only the BIOS version corresponding to initial release and may differ from that of the purchased motherboard.
- Users are welcome to download the latest BIOS version from our official website.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.1 Main



Contains basic system information for the MVP-6100.

WARNING:

Changing BIOS settings may lead to incorrect controller behavior and possible inability to boot. In such a case, Section 3.2.9:Clear CMOS Jumper provides instruction on clearing the CMOS and restoring default settings

BIOS Information

Shows current system BIOS Vendor, BIOS Version, Build Date, MRC Version, GOP Version and ME FW Version.

System Information

Shows current system Project Name, CPU Board Version, CPU Branding String, CPU Stepping, GT Info, CPU Frequency, Total Memory, Memory Frequency, PCH SKU and Stepping.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

System Time/System Date

Allows adjustment of system time and date, as follows.


1. Highlight System Time or System Date using the up and down <Arrow> keys.
2. Enter new values using the keyboard and select <Enter>.
3. Select < Tab > to move between fields.



The date must be entered in MM/DD/YY format, and the time in HH:MM:SS. The time is in 24-hour format. For example, 5:30 A.M. appears as 05:30:00, and 5:30 P.M. as 17:30:00.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.2 Advanced




CAUTION:

Setting incorrect or conflicting values in Advanced BIOS Setup may cause system malfunction.

Accesses advanced options of the MVP-6100.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.2.1 CPU Configuration



Hyper-Threading

Enabled for Windows XP and Linux (optimized for Hyper-Threading Technology) and Disabled for other OS (not optimized for Hyper-Threading Technology). When Disabled only one thread per enabled core is enabled.

Active Processor Cores

Number of cores to enable in each processor package.

Intel (VMX) Virtualization Technology

When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Intel® SpeedStep™

Allows more than two frequency ranges to be supported.


Intel® Speed Shift Technology)

Enables/disables Intel® Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow hardware controlled P-states.

TCC Activation Offset

Offset from factory set TCC activation temperature at which the Thermal Control Circuit must be activated. TCC will be activated at: TCC Activation Temp - TCC Activation Offset. TCC Activation Offset range is 0 to 63.

B.2.2 Power Management



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

State After G3

Specifies the state to go to when power is re-applied after a power failure (G3 state).

RTC Wake system from S5

Enables/disables System Wake on Alarm event. FixedTime sets system to wake on the hr::min::sec specified, DynamicTime sets system to wake ay the current time + Increase minute(s).

Ring Wake

Enables/disables RI ping for Wake On Ring function (PCH PME# signal).

PCIe Wake


Enables/disables PCI Express wake capability.

I219 LAN Wake

Enables/disables onboard LAN I219 wake capability.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.2.3 Serial Console Configuration



COM1

Console Redirection

Enables/disables SIO COM1 Console Redirection.

Console Redirection Settings

Specify how the host computer and the remote computer (in use) exchange data. Both computers should have the same or compatible settings.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

COM SOL (Pci Bus0,Dev22.Fun3)


Console Redirection

Enables/disables PCI SOL Console Redirection.

Console Redirection Settings

Specify how the host computer and the remote computer (in use) exchange data. Both computers should have the same or compatible settings.

B.2.4 USB Configuration



USB Mass Storage Driver Support

Enables/disables USB mass storage driver support.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

USB transfer time-out

The time-out value for Control, Bulk, and Interrupt transfers.

Device reset time-out

USB mass storage device Start Unit command time-out.

Device power-up delay

Maximum time the device will take before it properly reports itself to the Host Controller, where Auto uses default value for Root port 100ms, and for Hub port the delay is taken from Hub descriptor.

B.2.5 TPM 2.0 Configuration



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Security Device Support

Enables/disables BIOS support for security device. OS will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

SHA-1 PCR Bank

Enables/disables SHA-1 PCR Bank.

SHA256 PCR Bank

Enables/disables SHA256 PCR Bank.

Pending Operation

Schedules Operation for the Security Device. Computer will reboot during restart in order to change State of Security Device.

Platform Hierarchy

Enables/disables Platform Hierarchy.

Storage Hierarchy

Enables/disables Storage Hierarchy.

Endorsement Hierarchy

Enables/disables Endorsement Hierarchy.

TPM 2.0 UEFI Spec Version

Selects TCG2 Spec Version Support.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Physical Presence Spec Version

Directs OS to support PPI Spec Version 1.2 or 1.3. Some HCK tests may not support 1.3.

Device Select

TPM 1.2 restricts support to TPM 1.2 devices, TPM 2.0 restricts support to TPM 2.0 devices, Auto supports both with default TPM 2.0 devices if not found, TPM 1.2 devices will be enumerated.

B.2.6 AMT Configuration



AMT BIOS Features


When disabled, AMT BIOS features are no longer supported and user is no longer able to access MEBx Setup.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

MEBx Hotkey Pressed

Enables/disables automatic MEBx hotkey press.

B.2.7 Onboard Devices Configuration



COM1 Control

Selects COM1 mode from RS232, RS422 or RS485.

COM2 Control

Selects COM2 mode from RS232, RS422 or RS485.

LAN #1 (Intel I219)

Enables/disables I219 LAN1.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


LAN #2 (Intel I211AT)

Enables/disables I211 LAN2.

LAN #3 (Intel I211AT)

Enables/disables I211 LAN3.

B.2.8 NCT6106D HW Monitor




Displays CPU/Board Temperatures, System/BP fan speeds, and various Voltages.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

System Fan Control Mode

Configures fan control mode from among Manual Mode, Auto Mode, and SMART FAN IV.

Manual Mode




Allows configuration of a set fan duty cycle.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Auto Mode


Fan runs at automatic speed for optimal thermal solution.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

SMART FAN IV

Four temperatures and four fan duty cycles, with three available fan speed presets, can be user-configured.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.2.9 BIOS Watchdog Timer




BIOS POST Watchdog

Disable disables WatchDog Timer, Second Mode enables Watchdog Timer in second mode, Minute Mode enables Watchdog Timer in minute mode.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


B.2.10 NVME Configuration



Displays NVMe device status.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.2.11 Network Stack Configuration




Network Stack

Enables/disables UEFI Network Stack.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3 Chipset



WARNING:


Setting incorrect or conflicting values in Chipset BIOS Setup may cause system malfunction.

Above 4G Decoding

Enables/disables 64bit-capable devices to be decoded in Above 4G Address Space (only when system supports 64-bit PCI Decoding).

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3.1 System Agent (SA) Configuration




System Agent (SA) Configuration

Displays and configures VT-d capability and provides settings for Memory, Graphics, and DMI/OPI configuration.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3.1.1 Memory Configuration




Memory Configuration

Displays memory speed, size, maker, and configuration.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3.1.2 Graphics Configuration



Primary Display

Selects IGFX/PEG/PCH PCI(e) Graphics device to be Primary Display, SG enables Switchable Gfx.

Internal Graphics

Keeps IGFX enabled based on Setup options.

GTT Size

Selects GTT Size.

Aperture Size

Selects Aperture Size.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


DVMT Pre-Allocated

Selects DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device.

DVMT Total Gfx Mem

Selects DVMT5.0 Total Graphic Memory size used by Internal Graphics Device.

B.3.1.3 DMI/OPI Configuration



DMI/OPI Configuration


Displays DMI link speed and width.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

DMI Max Link Speed

Sets DMI Speed from among Gen1/Gen2/Gen3.

B.3.2 PCH-IO Configuration




PCH-IO Configuration

Configures SATA, Security, and HD Audio.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3.2.1 SATA And RST Configuration



SATA Mode Selection

Determines how SATA controller(s) operate.

SATA Controller Speed

Sets maximum speed the SATA controller can support.

M.2 Storage

Enables/disables M.2 Storage

CFast Card

Enables/disables CFast Card.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Hot Plug

Designates the port as Hot Pluggable.

SATA HDD 1

Enables/disables SATA HDD 1.

SATA HDD 2

Enables/disables SATA HDD 2.

SATA HDD 3


Enables/disables SATA HDD 3.

SATA HDD 4

Enables/disables SATA HDD 4.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3.2.2 Security Configuration




BIOS Lock

Enables/disables PCH BIOS Lock Enable. Required to be enabled to ensure SMM flash protection.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3.2.3 HD Audio Configuration




Audio Output Selection

Selects Audio Output.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3.2.4 M.2 Device Configuration




M.2 Port Device Link Selection

Configures M.2 port PCIe Link as X1 or X2.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.3.3 Backplane PCIe Configuration



Displays backplane type, link speed, and width.

B.3.4 BP PEG #1

Speed

Controls PCIe max speed.

Max. detection time

Configures max detection time for installed device (Range: 100-65535ms).

Min. time PERST active

Configures min PERST# signal active time (Range: 20-65535ms).

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Max. time PERST deactive

Configures max time PCIe device must enter L0 after PERST is deasserted (Range: 100-65535ms).

B.3.5 BP PCH PCIe x4 #1

Speed

Controls PCIe max speed.

Max. detection time

Configures max detection time for installed device (Range: 100-65535ms).

Min. time PERST active

Configures min PERST# signal active time (Range: 20-65535ms).

Max. time PERST deactive

Configures max time PCIe device must enter L0 after PERST is deasserted (Range: 100-65535ms).

B.3.6 BP PCH PCIe x4 #2

Speed

Controls PCIe max speed.

Max. detection time

Configures max detection time for installed device (Range: 100-65535ms).

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Min. time PERST active

Configures min PERST# signal active time (Range: 20-65535ms).

Max. time PERST deactive

Configures max time PCIe device must enter L0 after PERST is deasserted (Range: 100-65535ms).

B.3.7 BP PCH PCIe x1 #1

Speed

Controls PCIe max speed.

Max. detection time

Configures max detection time for installed device (Range: 100-65535ms).

Min. time PERST active


Configures min PERST# signal active time (Range: 20-65535ms).

Max. time PERST deactive

Configures max time PCIe device must enter L0 after PERST is deasserted (Range: 100-65535ms).

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.4 Security



If only the Administrator password is set, access is limited and the password requested on Setup. If User password is set, it acts as a power-on password and must be entered to boot or enter setup.

Administrator Password

Sets Administrator Password.

User Password


Sets User Password.

Secure Boot Menu

Configures Secure Boot.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.4.1 Secure Boot Menu



Secure Boot Control

Active if Secure Boot is Enabled, Platform Key (PK) is enrolled and the System is in User mode. Mode change requires platform reset.

Secure Boot Mode


Selects from Standard or Custom. In Custom, Secure Boot Policy variables can be configured by a physically present user without full authentication.

Key Management

Enables expert users to modify Secure Boot Policy variables without full authentication.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.5 Boot



Setup Prompt Timeout

Number of seconds before setup activation key is launched, with 65535(0xFFFF) setting indefinite waiting.

Bootup Num-Lock State

Sets keypad Number Lock status following boot.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Quiet Boot

Option	Description
Disabled	Directs BIOS to display POST messages
Enabled	Directs BIOS to display the OEM logo.

Fast Boot

Option	Description
Disabled	Directs BIOS to perform all POST tests.
Enabled	Directs BIOS to skip certain POST tests to boot faster.

While enabling Fast Boot can reduce system ready time, some prerequisites can reduce effectiveness.

Boot Configuration


Specifies the priority of boot devices, all of which are detected during POST and displayed. Target Boot Option # and click to select the desired device.

UEFI USB Hard Drive Disk Drives BBS Priorities

Specifies Boot Device Priority sequence from available UEFI USB Drives.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

B.6 Save & Exit



Save Changes and Exit

Exits system setup after saving the changes.

Discard Changes and Exit

Exits system setup without saving any changes.

Save Changes and Reset

Resets the system setup after saving changes.

Discard Changes and Reset

Resets system setup without saving any changes.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Save Changes

Saves Changes so far to any of the setup options.

Discard Changes

Discards Changes so far to any of the setup options.

Restore Defaults

Sets all BIOS options to default settings, designed for maximum system stability but less than maximum performance. Select Restore Defaults if the computer encounters system configuration problems.

Save as User Defaults

Saves all changes so far as User Defaults.

Restore User Defaults

Restores user defaults to all setup options.

Launch EFI Shell from filesystem device

Attempts to launch EFI Shell application (Shell.efi) from one of the available filesystem devices.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Appendix C Watchdog Timer (WDT) Function Library

This appendix describes use of the watchdog timer (WDT) function library for the MVP-6100 controller. The watchdog timer is a hardware mechanism provided to reset the system if the operating system or an application stalls. After starting, the watchdog timer in the application must be periodically reset before the timer expires. Once the watchdog timer expires, a hardware-generated signal is sent to reset the system.

C.1 WDT with API/Windows

The WDT API library files and a demo program (incl. source code) can be downloaded from: https://www.adlinktech.com/Products/Industrial_PCs_Fanless_Embedded_PCs/ExpandableFanlessEmbeddedComputers/MVP-6100_Series

To use the WDT function library for the MVP-6100, include the header file WDT.h and linkage library WDT.lib in the C++ project.

InitWDT

Initializes the watchdog timer function. Must be called before the invocation of any other WDT function.

Syntax

C/C++

```
BOOL InitWDT()
```

Parameters

None

Return codes

TRUE if watchdog timer is successfully initialized.

FALSE if watchdog timer fails to initialize.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

SetWDT

Sets the timeout value of the watchdog timer. There are two parameters for this function to indicate the timeout ticks and unit. ResetWDT or StopWDT should be called before the expiration of watchdog timer, or the system will reset.

Syntax

C/C++

```
BOOL SetWDT(BYTE tick, BYTE unit)
```

Parameters

`tick`

Specify the number of ticks for watchdog timer. A valid value is 1 - 255.

`unit`

Specifies the timeout ticks of the watchdog timer.

Value	Description
0	The unit for one tick is one second. For example, when one tick is specified as 100 and the unit as 0, the timeout value is 100 seconds.
1	The unit for one tick is one minute. For example, whenone tick is specified as 100 and the unit as 1, the timeout value is 100 minutes.

Return codes

TRUE if timeout value of watchdog timer is successfully set.

FALSE if timeout value of watchdog timer is failed to set.

StartWDT

Start the watchdog timer function. Once the StartWDT is invoked, the watchdog timer starts. ResetWDT or StopWDT should be called before the expiration of watchdog timer, or the system will reset.

Syntax

C/C++

```
BOOL StartWDT()
```


LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Parameters

None

Return codes

TRUE if watchdog timer is successfully started.

FALSE if watchdog timer is failed to start.

ResetWDT

Reset the watchdog timer. The invocation of ResetWDT allows restoration of the watchdog timer to the initial timeout value specified in SetWDT function. ResetWDT or StopWDT should be called before the expiration of the watchdog timer, or the system will reset.

Syntax

C/C++

```
BOOL ResetWDT()
```

Parameters

None

Return codes

TRUE if watchdog timer is successfully reset.

FALSE if watchdog timer fails to reset.

StopWDT

Stops the watchdog timer.

Syntax

C/C++

```
BOOL StopWDT()
```

Parameters

None

Return codes

TRUE if watchdog timer is successfully stopped.

FALSE if watchdog timer fails to stop.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

C.2 WDT with DOS/Linux

Under Linux, please program the WDT function using the LPC IO registers according to the sample program as follows.

```
#include <dos.h>
#include <stddef.h>
#include <stdio.h>
/* Config LPC IO NCT6102D to enter config mode */
EnterConfig(void)
{
outp(0x4E, 0x87);
outp(0x4E, 0x87);
}
/* Config LPC IO to exit config mode */
ExitConfig(void)
{ outp(0x4E, 0xAA);
 }
/* Read byte from LPC IO register */
unsigned char r_reg(unsigned char regoffset)
{ outp(0x4E, regoffset);
return inp(0x4F); }
/* Write byte to LPC IO register */
void w_reg(unsigned char regoffset, unsigned char
data)
{ outp(0x4E, regoffset); outp(0x4F, data);
}
main(void)
{
unsigned int    count;
/* print program title  */
printf("-----------------MXC-6400 WDT Demo-----------
-----\n");
```

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

```
printf("Init and config GPIO
ports<<<<<<<<<<<<<<<<<<<<<<<<\n");
printf("-----------------------------------------------
----\n");
EnterConfig();
/* config WDT registers */
w_reg(0x07,0x08);
/* enable keyboard interrupt to reset WDT timeout
value */
w_reg(0xF2,r_reg(0xF2)|0x40);
/* set unit as second */
w_reg(0xF0,r_reg(0xF0)&~0x04);
/* start the Watchdog */
w_reg(0x30,0x01);
/* set timeout value as 30 seconds */
/* WDT start automatically while timeout value is set
*/
w_reg(0xF1,0x1E);


printf("-----------------------------------------------
-----\n");
printf("WDT is set and counting down
now.<<<<<<<<<<<<<<<<<\n");
printf("-----------------------------------------------
-----\n");
for(count=30;count!=0;count--)
{ printf("Countdown %2d :  .\n",count);
/* reset WDT timeout value to 10 seconds */
/* w_reg(0x73,0x0A); */
sleep(1);
}
/* disable WDT */
/* WDT stop while timeout value is set to zero */
w_reg(0x30,0x00);
```

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

```
printf("WDT is disable. Program is terminating.");
ExitConfig();
return 0;
}
```

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Appendix D Digital Input/Output Function Library

DI/O provides input/output to support inter-device communications. Simple programming guides allow easy transmission of digital signals between the system and attached peripherals.

DI/O with API/Windows

Matrix DI/O API library files and a demo program (incl. source code) can be downloaded from http://www.adlinktech.com.

To use the DI/O function library for MVP-6100 series, include the header file awl.h and linkage library awl.lib in the C++ project. DI/O functions are as follows.

AwlDioGetValue

Reads the digital logic state of a digital input line.

Syntax

C/C++

```
int __stdcall AwlDioGetValue(int Index)
```

Parameter(s)

Index

Indexes the digital logic state of MVP-6100 digital input channels 1 to 8 (bit 0 to 7)

Return codes

```
0: Operation Success
-1: Operation Failed
```

AwlDioSetValue

Sets the digital logic state of the digital output line.

AwlDioGetValue

Reads the digital logic state of a digital input line.

Syntax

C/C++

```
int __stdcall AwlDioGetValue(int Index , int
     Value)
```

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Parameter(s)

Index

Indexes the digital logic state of MVP-6100 digital input channels 1 to 8 (bit 0 to 7)

Value

Sets the digital logic state of MVP-6100 digital output channels 1 to 8 (bit 0 to 7) to 0 or 1.

Return codes

```
0: Operation Success
-1: Operation Failed
```

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Important Safety Instructions

For user safety, please read and follow all instructions, Warnings, Cautions, and Notes marked in this manual and on the associated device before handling/operating the device, to avoid injury or damage.

- Read these safety instructions carefully.
- Keep the User's Manual for future reference.
- Read the Specifications section of this manual for detailed information on the recommended operating environment.
- The device can be operated at an ambient temperature of 45ºC with DC input, and 35ºC with adapter input.
- It is recommended that the device be installed in Information Technology Rooms that are in accordance with Article 645 of the National Electrical Code and NFPA 75.
- To avoid electrical shock and/or damage to device:
  - Keep device away from water or liquid sources.
  - Keep device away from high heat or humidity.
  - Keep device properly ventilated (do not block or cover ventilation openings).
  - Always use recommended voltage and power source settings.
  - Always install and operate device near an easily accessible electrical outlet.
  - Secure the power cord (do not place any object on/over the power cord).
  - Only install/attach and operate device on stable surfaces and/or recommended mountings.
  - The power cord must be connected to a socket or outlet with a ground connection.
- If the device will not be used for long periods of time, turn off and unplug from its power source.
- Never attempt to repair the device, which should only be serviced by qualified technical personnel using suitable tools.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

- A Lithium-type battery may be provided for uninterrupted backup or emergency power.



Risk of explosion if battery is replaced with one of an incorrect type; please dispose of used batteries appropriately.

- This equipment is not suitable for use in locations where children are likely to be present.
- The device must be serviced by authorized technicians when:
  - The power cord or plug is damaged
  - Liquid has entered the device interior
  - The device has been exposed to high humidity and/or moisture
  - The device is not functioning or does not function according to the User's Manual
  - The device has been dropped and/or damaged and/or shows obvious signs of breakage
- Disconnect the power supply cord before loosening the thumbscrews and always fasten the thumbscrews with a screwdriver before starting the system up
- It is recommended that the device be installed only in a server room or computer room where access is:
  - Restricted to qualified service personnel or users familiar with restrictions applied to the location, reasons therefor, and any precautions required
  - Only afforded by the use of a tool or lock and key, or other means of security, and controlled by the authority responsible for the location



BURN HAZARD

Hot surface! Do not touch! Touching this surface could result in bodily injury. To reduce risk, allow the surface to cool before touching.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Consignes de Sécurité Importante

S'il vous plaît prêter attention stricte à tous les avertissements et mises en garde figurant sur l'appareil, pour éviter des blessures ou des dommages.

- *Lisez attentivement ces consignes de sécurité.*
- *Conservez le manuel de l'utilisateur pour pouvoir le consulter ultérieurement.*
- *Lisez la section Spécifications de ce manuel pour des informations détaillées sur l'environnement d'exploitation recommandé.*
- *L'appareil peut être utilisé à une température ambiante de 45°C avec entrée CC pour les série MVP-61; 35ºC avec entrée adaptateur pour la série MVP-61.*
- *Il est recommandé d'installer l'appareil dans des salles de technologie de l'information conformes à l'article 645 du National Electrical Code et à la NFPA 75.*
- *Pour éviter les chocs électriques et/ou d'endommager l'appareil:*
  - *Tenez l'appareil à l'écart de toute source d'eau ou de liquide.*
  - *Tenez l'appareil à l'écart d'une forte chaleur ou d'une humidité élevée.*
  - *Maintenez l'appareil correctement ventilé (n'obstruer ou ne couvrez pas les ouvertures de ventilation).*
  - *Utilisez toujours les réglages de tension et de source d'alimentation recommandés.*
  - *Installez et utilisez toujours l'appareil près d'une prise de courant facilement accessible.*
  - *Fixez le cordon d'alimentation (ne placez aucun objet sur le cordon d'alimentation).*
  - *Installez/fixez et utilisez l'appareil uniquement sur des surfaces stables et/ou sur les fixations recommandées.*
  - *Le cordon d'alimentation doit être connecté à une prise ou à une prise de courant avec mise à la terre.*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

- Si l'appareil ne doit pas être utilisé pendant de longues périodes, éteignez-le et débranchez-le de sa source d'alimentation
- *N'essayez jamais de réparer l'appareil, qui ne doit être réparé que par un personnel technique qualifié à l'aide d'outils appropriés*
- *Une batterie de type Lithium peut être fournie pour une alimentation de secours ininterrompue ou d'urgence.*



ATTENTION: Risque d'explosion si la pile est remplacée par une autre de type incorrect. Veuillez jeter les piles usagées de façon appropriée.

- *Cet équipement ne convient pas à une utilisation dans des lieux pouvant accueillir des enfants.*
- *L'appareil doit être entretenu par des techniciens agrees lorsque:*
- *Le cordon d'alimentation ou la prise est endommagé(e)*
- *Un liquide a pénétré à l'intérieur de l'appareil.*
- *L'appareil a été exposé à une forte humidité et/ou de la buée.*
- *L'appareil ne fonctionne pas ou ne fonctionne pas selon le manuel de l'utilisateur.*
- *L'appareil est tombé et/ou a été endommagé et/ou présente des signes évidents de dommage.*
- *Débranchez le cordon d'alimentation avant de desserrer les vis à oreilles et serrez toujours les vis à oreilles avec un tournevis avant de mettre le système en marche.*
- *Il est recommandé d'installer l'appareil uniquement dans une salle de serveurs ou une salle informatique où l'accès est:*
  - *Réservé au personnel de service qualifié ou aux utilisateurs familiarisés avec les restrictions appliquées à l'emplacement, aux raisons de ces restrictions et toutes les précautions requises*
  - *Uniquement autorisé par l'utilisation d'un outil, d'une serrure et d'une clé, ou d'un autre moyen de sécurité, et contrôlé par l'autorité responsable de l'emplacement.*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

	***RISQUE DE BRÛLURES*** ***Partie chaude!*** *Ne touchez pas cette surface, cela pourrait entraîner des blessures. Pour éviter tout danger, laissez la surface refroidir avant de la toucher.*

This page intentionally left blank.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Getting Service

Ask an Expert: http://askanexpert.adlinktech.com

ADLINK Technology, Inc.
9F, No.166 Jian Yi Road, Zhonghe District
New Taipei City 235, Taiwan
Tel: +886-2-8226-5877
Fax: +886-2-8226-5717
Email: service@adlinktech.com

Ampro ADLINK Technology, Inc.
5215 Hellyer Avenue, #110
San Jose, CA 95138, USA
Tel: +1-408-360-0200
Toll Free: +1-800-966-5200 (USA only)
Fax: +1-408-360-0222
Email: info@adlinktech.com

ADLINK Technology (China) Co., Ltd.
300 Fang Chun Rd., Zhangjiang Hi-Tech Park
Pudong New Area, Shanghai, 201203 China
Tel: +86-21-5132-8988
Fax: +86-21-5132-3588
Email: market@adlinktech.com

ADLINK Technology GmbH
Hans-Thoma-Straße 11
D-68163 Mannheim, Germany
Tel: +49-621-43214-0
Fax: +49-621 43214-30
Email: emea@adlinktech.com

Please visit the Contact page at www.adlinktech.com for information on how to contact the ADLINK regional office nearest you:

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000