ADLINK Vision Software (AVS)

Function Reference Manual

Manual Revision: 1.0

Revision Date: February 7, 2022

Part No: 50M-00060-1000

LEADING EDGE COMPUTING

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Revision History

Revision	Release Date	Description of Change(s)
1.0	2022-02-07	Initial release

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Preface

Copyright © 2022 ADLINK Technology, Inc.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Disclaimer

The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

Environmental Responsibility

ADLINK is committed to fulfill its social responsibility to global environmental preservation through compliance with the European Union's Restriction of Hazardous Substances (RoHS) directive and Waste Electrical and Electronic Equipment (WEEE) directive. Environmental Protection is a top priority for ADLINK. We have enforced measures to ensure that our products, manufacturing processes, components, and raw materials have as little impact on the environment as possible. When products are at their end of life, our customers are encouraged to dispose of them in accordance with the product disposal and/or recovery programs prescribed by their nation or company.

Trademarks

Product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Conventions

Take note of the following conventions used throughout this manual to make sure that users perform certain tasks and instructions properly.



Additional information, aids, and tips that help users perform tasks.



Information to prevent ***minor*** physical injury, component damage, data loss, and/or program corruption when trying to complete a task.



Information to prevent ***serious*** physical injury, component damage, data loss, and/or program corruption when trying to complete a specific task.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Table of Contents

Revision History ii

Preface iii

1 Introduction 1
- 1.1 Environment 1
- 1.2 AVS Installation 1
- 1.3 AVS Functions & Parameters 2
- 1.4 AVS Sample Programs 2
- 1.5 AVS Installation Folder 3
- 1.5.1 Linux 3
- 1.5.2 Windows 4
- 1.6 Sample Reference Code 5
- 1.6.1 Include Header File 5
- 1.6.2 Get Product Handle 6

2 AVS Parameters Reference 7
- 2.1 Product Name 7
- 2.2 Product Features 7
- 2.3 Edge Trigger 8
- 2.4 PoE 8
- 2.5 PoE Power Management 9
- 2.6 AVS Error Code 10

3 Function Library 11
- 3.1 List of Functions 11
- 3.2 Function Library 13
- 3.2.1 Common 13
- 3.2.2 USB Port Control 19
- 3.2.3 External Power Supply 21
- 3.2.4 Power over Ethernet 23
- 3.2.5 Trigger over Ethernet 30

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Important Safety Instructions..... 43

Getting Service 47

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1 Introduction

ADLINK Vision Software (AVS) is the application programming interface (API) for ADLINK vision products. AVS allows developers to build applications in Linux and Windows operating systems via C/C++, C#/VB.NET support. Along with the APIs, AVS also includes product drivers and a set of sample programs and documentation.

1.1 Environment

Platform	x86, x86-x64
OS	Linux: Ubuntu 12.04 LTS (kernel 3.13) and above
	Windows: 7/10
Programming Language	Linux: C/C++
	Windows: C/C++, C#, VB.NET

1.2 AVS Installation

Linux	Debian, DKMS are a must for AVS. $sudo apt-get install dkms $tar xvf **AVS-SDK_xxx.tar** $cd **AVS-SDK_xxx** $./install.sh
Windows	Execute **AVS-SDK_x.x.x.xxxx.exe**

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.3 AVS Functions & Parameters

AVS Function	Description	Installation Folder
General SDK functions	Retrieves product handle and device information	\AVS_SDK.h
Feature functions	Basic functions	\Feature*.h
AVS Parameter Reference	AVS parameters are grouped by C/C++ enumerations	\Common\I_common.h

1.4 AVS Sample Programs

Type	Description
GUI samples	An entry point for quickly performing samples with a GUI interface. (Windows only)
Console samples	Applications that can be run from a command prompt in Windows and Linux.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.5 AVS Installation Folder

1.5.1 Linux

Type	Installation Folder	File	Description
Include	/usr/local/include/ADLINK/AVS	AVS_SDK.h	Header file required for General SDK functions
	/usr/local/include/ADLINK/AVS/Common/	I_common.h	Header file required for AVS parameters
	/usr/local/include/ADLINK/AVS/Feature/	ExPowerSupply.h PowerController.h PoE.h ToE.h Fan.h	Header file required for basic functions
Library	/usr/local/lib/	libAVS_SDK.so libAVS_Product.so libAVS_CoreSDK.so	Exports API function definitions, required for Visual C/C++ applications
Sample Program	/usr/local/src/ADLINK/AVS/Sample	Build Sample $cd /usr/local/src/ADLINK/AVS/Sample $make Execute Sample $cd /usr/local/src/ ADLINK/AVS/Sample/bin $sudo ./AVS_GetSDKInfo	

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.5.2 Windows

Type	Installation Folder	File	Description
Include	\ADLINK\AVS\ Include\ C++	AVS_SDK.h I_common.h ExPowerSupply.h PowerController.h	Header file required for all C/C++ applications
	\ADLINK\AVS\ Include\ VB.NET	AVS_SDK.vb I_common.vb ExPowerSupply.vb PowerController.vb	Function definitions required for all VB.Net applications
	\ADLINK\AVS\ Include\ C#	AVS_SDK.cs I_common.cs ExPowerSupply.cs PowerController.cs	Function definitions required for all C# applications
DLL	\ADLINK\AVS\Dll	AVS_SDK.dll AVS_Product.dll AVS_CoreSDK.dll	Dynamic link library files required for all applications
Library	\ADLINK\AVS\Dll	AVS_SDK.lib	Exports API function definitions, required for all Visual C/C++ applications
Sample Program	\ADLINK\AVS\ Sample	Console: SampleGUI.exe GUI: VC++, C#/VB.NET	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.6 Sample Reference Code

1.6.1 Include Header File

This code sample shows how to include a header file.

```
#ifdef __linux__
#include "/usr/local/include/ADLINK/AVS/
     AVS_SDK.h"
#include "/usr/local/include/ADLINK/AVS/Common/
     I_common.h"
#elif _WIN32
#include "Include/C++/AVS_SDK.h"
#include "Include/C++/Common/I_common.h"
#endif
```

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.6.2 Get Product Handle

This code sample shows how to get the product handle and product Information.

```
using namespace std;
/*Show SDK Information*/
char buffer[256];
if (AVS_GetSDKInfo(buffer, sizeof(buffer)) ==
     AVS_FUN_SUCCESS)
cout << buffer << endl;
...
/*Show Product Information*/
unsigned int nums = AVS_GetProductNums();
if (nums <= 0)
{
     cout << "Find no device!" << endl;
     return 0;
}

void* handle;
unsigned int devIndex = 0;
handle = AVS_GetProductHandle(devIndex);
if (!handle)
{
     cout << "AVS_GetProductHandle Error\n" <<
     endl;
     return 0;
}

if (AVS_GetProductInfo(handle, buffer,
     sizeof(buffer)) == AVS_FUN_SUCCESS)
     cout << buffer << endl;
...
```

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2 AVS Parameters Reference

AVS parameters are grouped by enumerations and can be found in the header file “I_common”.

2.1 Product Name

ADLINK vision products supported by AVS SDK are grouped by **AVS_PRODUCT_TYPE**.

String Identifier	Product Name
AVS_PRODUCT_UNKNOWN	Unknown product
AVS_PRODUCT_PCIEGIE72	PCIe-GIE72
AVS_PRODUCT_PCIEGIE74	PCIe-GIE74
AVS_PRODUCT_PCIEGIE72PRO	PCIe-GIE72 PRO
AVS_PRODUCT_PCIEGIE74PRO	PCIe-GIE74 PRO
AVS_PRODUCT_PCIEU304	PCIe-U304
AVS_PRODUCT_PCIEU308	PCIe-U308
AVS_PRODUCT_PCIEU312	PCIe-U312
AVS_PRODUCT_PCIE10GPOE	PCIe-10GPoE

2.2 Product Features

AVS parameters are grouped by **AVS_FEATURE_TYPE**.

String Identifier	Product Feature
AVS_FEATURE_POWERCONTROLLER	USB3 Power Management
AVS_FEATURE_POE	Power over Ethernet (PoE)
AVS_FEATURE_TOE	Trigger over Ethernet (ToE)
AVS_FEATURE_DIO	Digital Input / Output
AVS_FEATURE_EXTERNALPOWERSUPPLY	External power supply detection
AVS_FEATURE_NUMS	The number of the product feature

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.3 Edge Trigger

Edge Trigger parameters are defined by **AVS_ EDGETRIGGER_TYPE**.

String Identifier	Parameter
AVS_EDGETRIGGER_RISINGEDGE	Signal rising edge trigger
AVS_EDGETRIGGER_FALLINGEDGE	Signal falling edge trigger
AVS_EDGETRIGGER_CHANGINGEDGE	Signal changing edge trigger
AVS_EDGETRIGGER_NUMS	The number of the edge trigger type

2.4 PoE

PoE parameters are defined by **AVS_POEPROPERTY_TYPE**.

String Identifier	Parameter
AVS_POEPROPERTY_POEHWSETTING	Power sourcing equipment (PSE) hardware setting
AVS_POEPROPERTY_POEINITIALSTATE	Power sourcing equipment (PSE) initial power
AVS_POEPROPERTY_OVERTEMPERATURE	Check if the device temperature is over the high temperature (degrees C)
AVS_POEPROPERTY_CURRENTTEMPERATURE	Get the current temperature
AVS_POEPROPERTY_CONSUMEPOWER	The consumer power (Watt)
AVS_POEPROPERTY_REMAINPOWER	The left power (Watt)
AVS_POEPROPERTY_POWERBUDGET	The total power budget (Watt)
AVS_POEPROPERTY_NUMS	The number of the PoE property

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.5 PoE Power Management

PoE Power Management parameters are defined by **AVS_POEPORTPROPERTY_TYPE**.

String Identifier	Parameter
AVS_POEPORTPROPERTY_CURRENT	The current of a port (A)
AVS_POEPORTPROPERTY_VOLT	The voltage of a port (V)
AVS_POEPORTPROPERTY_POECLASS	The power class of a port
AVS_POEPORTPROPERTY_POWERGOOD	Check if the power is good on a port
AVS_POEPORTPROPERTY_LASTPOWERSTATE	Retrieve the last power state of a port. If the PoE status of a port is currently off, this function is used to retrieve the port's last PoE status, which is used to determine the PoE cut off status.
AVS_POEPORTPROPERTY_NUMS	The number of the PoE port properties

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.6 AVS Error Code

An AVS error code is defined by **AVS_FUN_RETURNVAL**. No error occurs if the API returns a value >= 0, or a negative value.

Error Code	Definition	Description
0	AVS_FUN_SUCCESS	Execution successful
-1	AVS_FUN_FAILED	Execution failed
-5	AVS_FUN_NOTDEFINED	Unsupported function
-11	AVS_FUN_INVALIDPARA	The parameters are invalid
-13	AVS_FUN_NOTINIT	The object is not initialized
-100	AVS_FUN_BUSY	The system is busy. The device has timed out, or is not currently able to reply.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3 Function Library

3.1 List of Functions

Category (Header File)	Function	Product
Common (AVS_SDK.h)	AVS_GetProductNums()	All Products
	AVS_GetSDKInfo()	
	AVS_GetProductHandle()	
	AVS_GetProductInfo()	
	AVS_GetProductType()	
	AVS_GetProductSN()	
	AVS_GetFeatureList()	
	AVS_GetCardID()	
USB Port Control (PowerController.h)	AVS_PowCtrlGetPortNums()	PCIe-U300 Series
	AVS_PowCtrlSetPortEnable()	
	AVS_PowCtrlGetPortEnable()	
External Power Supply (ExPowerSupply.h)	AVS_ExPowSupGetNums()	All Products
	AVS_ExPowSupGetState()	
Power over Ethernet (PoE.h)	AVS_PoEGetPortNums()	PCIe-GIE Series PCIe-10G Series
	AVS_PoESetPortEnable()	
	AVS_PoEGetPortEnable()	
	AVS_PoESetPowConsumCalcModel()	
	AVS_PoEGetPowConsumCalcModel()	
	AVS_PoESetProtectTempRange()	
	AVS_PoEGetProtectTempRange()	
	AVS_PoEGetProperty()	
	AVS_PoEGetPortProperty()	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Category (Header File)	Function	Product
Trigger over Ethernet (ToE.h)	AVS_ToEGetPortNums()	PCIe-GIE7x PRO, PCIe-10G Series
	AVS_ToESendActionCommand()	
	AVS_ToESetActionCommand()	
	AVS_ToEGetActionCommand()	
	AVS_ToESetTriggerSource()	
	AVS_ToEGetTriggerSource()	
	AVS_ToESetTriggerEnable()	
	AVS_ToEGetTriggerEnable()	
	AVS_ToESetTriggerActivation()	
	AVS_ToEGetTriggerActivation()	
	AVS_ToESetOneTriggerAllMode()	
	AVS_ToEGetOneTriggerAllMode()	
	AVS_ToESetExTriggerDebounce()	
	AVS_ToEGetExTriggerDebounce()	
	AVS_ToEGetExTriggerDebounceUnit()	
	AVS_ToEGetTriggerCount()	
	AVS_ToEResetTriggerCount()	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2 Function Library

AVS supports the C/C++/C#/VB.NET programming languages. The following are examples of the C/C++ library.

3.2.1 Common

These functions are used to get the product handle and retrieve device information.

3.2.1.1 AVS_GetProductNums

Function Name	AVS_GetProductNums
Purpose	This function returns the total number of products installed in the system.
Category	Common
Header File	AVS_SDK.h
Syntax (C/C++)	unsigned int AVS_GetProductNums()
Parameter(s)	
Return Code	
Returns the total number of devices if return value >= 0. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.1.2 AVS_GetSDKInfo

Function Name	AVS_GetSDKInfo
Purpose	This function returns the SDK version information (e.g., driver version, SDK version)
Category	Common
Header File	AVS_SDK.h
Syntax (C/C++)	int AVS_GetSDKInfo(char* data, unsigned int bufsize)
Parameter(s)	
data: A string buffer indicating the parameters and information provided. Each parameter and information is split by a break line character '\n'. The format is Parameter Name:Parameter Information '\n' For example: Driver version:0.2.0.0929 SDK version:1.3.6.0121 **bufsize**: Indicates the size of the "data" buffer. The suggested value is 256.	
Return Code	
Returns the total number of devices if return value >= 0. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.1.3 AVS_GetProductHandle

Function Name	AVS_GetProductHandle
Purpose	Initializes the specified device and gets its handle. This should be called before other functions except those with no handle parameter.
Category	Common
Header File	AVS_SDK.h
Syntax (C/C++)	void* AVS_GetProductHandle(unsigned int index)
Parameter(s)	
index: Indicates the number of devices, beginning at 0 for the number of the first card, with the second card 1, and so on. This value should be less than (total numbers of the cards -1). The total number of the cards is acquired from AVS_GetProductNums.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.1.4 AVS_GetProductInfo

Function Name	AVS_GetProductInfo
Purpose	This function returns all the product information. (e.g., firmware version, product number)
Category	Common
Header File	AVS_SDK.h
Syntax (C/C++)	int AVS_GetProductInfo(void* handle, char* data, unsigned int bufsize)

Parameter(s)

handle: Acquired from the return value of AVS_GetProductHandle.
data: A string buffer indicating the parameters and information provided. Each parameter and information is split by a break line character '\n'. The format is
Parameter Name:Parameter Information '\n'
For example:
Product:PCIe-10GPoE
CPLDVersion:20210119_1610
MCUVersion:2.3
PN:91-64216-000E
SN:0123456789
PCBVersion:1
MAC0:00:30:64:35:c4:26
MAC1:00:30:64:35:c4:26
Bufsize: Indicates the size of the "data" buffer. The suggested value is 256.

Return Code

No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.1.5 AVS_GetProductType

Function Name	AVS_GetProductType
Purpose	Get the product type.
Category	Common
Header File	AVS_SDK.h
Syntax (C/C++)	int AVS_GetProductType(void* handle)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle.	
Return Code	
Returns AVS_PRODUCT_TYPE. No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.1.6 AVS_GetProductSN

Function Name	AVS_GetProductSN
Purpose	This function gets the product serial number (SN).
Category	Common
Header File	AVS_SDK.h
Syntax (C/C++)	int AVS_GetProductSN(void* handle, char* data, unsigned int bufsize)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle.	
data: Pointer of an allocated character buffer into the function copies the string.	
Bufsize: Indicates the size of the “data” buffer. The suggested value is 32.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.1.7 AVS_GetFeatureList

Function Name	AVS_GetFeatureList
Purpose	This function gets the product feature list.
Category	Common
Header File	AVS_SDK.h
Syntax (C/C++)	int AVS_GetFeatureList(void* handle, AVS_FEATURE_TYPE* list, unsigned int listsize)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **list**: Pointer of an allocated buffer into the function copies the string. **listsize**: Indicates the size of the “list” buffer. The suggested value is AVS_FEATURE_NUMS (AVS_FEATURE_NUMS is definded in I_common.h).	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.1.8 AVS_GetCardID

Function Name	AVS_GetCardID
Purpose	This function gets a numeric card ID that corresponds to the handle.
Category	Common
Header File	AVS_SDK.h
Syntax (C/C++)	int AVS_GetCardID(void* handle, int* id)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **id**: Indicates the card ID set by switch SW1, a value from 0 to 15. Card ID and SW1 switch settings correlate as shown. Refer to the table below.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

Card ID (id)	Hardware Switch			
	4	3	2	1
0	off	off	off	off
1	off	off	off	on
2	off	off	on	off
3	off	off	on	on
4	off	on	off	off
5	off	on	off	on
6	off	on	on	off
7	off	on	on	on
8	on	off	off	off
9	on	off	off	on
10	on	off	on	off
11	on	off	on	on
12	on	on	off	off
13	on	on	off	on
14	on	on	on	off
15	on	on	on	on

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.2 USB Port Control

This feature is used to control the power device.

3.2.2.1 AVS_PowCtrlGetPortNums

Function Name	AVS_PowCtrlGetPortNums
Purpose	This function gets a number of ports that correspond to the handle.
Category	USB Port Control
Header File	PowerController.h
Syntax (C/C++)	int AVS_PowCtrlGetPortNums(void* handle, unsigned int* nums)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **nums**: Number of ports.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.2.2 AVS_PowCtrlSetPortEnable

Function Name	AVS_PowCtrlSetPortEnable
Purpose	Controls power auto/off.
Category	USB Port Control
Header File	PowerController.h
Syntax (C/C++)	int AVS_PowCtrlSetPortEnable(void* handle, int* list, unsigned int listsize)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **list**: An array to control power auto/off of each port. The index of the array corresponds to the index of port, the element of the array indicates to enable or disable the power. **listsize**: The array must contain nums elements (nums is acquired from the return value of AVS_PowCtrlGetPortNums).	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.2.3 AVS_PowCtrlGetPortEnable

Function Name	AVS_PowCtrlGetPortEnable
Purpose	Retrieves power auto/off.
Category	USB Port Control
Header File	PowerController.h
Syntax (C/C++)	int AVS_PowCtrlGetPortEnable(void* handle, int* list, unsigned int listsize)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **list**: An array for receiving the power status from the ports. **listsize**: The array must contain nums elements (nums is acquired from the return value of AVS_PowCtrlGetPortNums).	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.3 External Power Supply

These functions are used for the status of the external power supply cables.

3.2.3.1 AVS_ExPowSupGetNums

Function Name	AVS_ExPowSupGetNums
Purpose	Get the number of the connected external power cable.
Category	External Power Supply
Header File	ExPowerSupply.h
Syntax (C/C++)	int AVS_ExPowSupGetNums(void* handle, unsigned int* nums)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **nums**: Number of the connected external power cable.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.3.2 AVS_ExPowSupGetState

Function Name	AVS_ExPowSupGetState
Purpose	Get the detection results of external power supply cables.
Category	External Power Supply
Header File	ExPowerSupply.h
Syntax (C/C++)	int AVS_ExPowSupGetState(void* handle, int* statelist, unsigned int listsize)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **statelist**: An array for detecting results of external power cables. “0” indicates power is not supplied, the other values indicate power is supplied. **listsize**: The array must contain nums elements (nums is acquired from the return value of AVS_ExPowSupGetNums).	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.4 Power over Ethernet

This feature is for SmartPoE, the PoE power management functions.

3.2.4.1 AVS_PoEGetPortNums

Function Name	AVS_PoEGetPortNums
Purpose	Retrieve the number of the power over Ethernet.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoEGetPortNums(void* handle, unsigned int* nums)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **nums**: Return the number of the power over Ethernet.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.4.2 AVS_PoESetPortEnable

Function Name	AVS_PoESetPortEnable
Purpose	Controls power auto/off.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoESetPortEnable(void* handle, int* list, unsigned int listsize)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **list**: An array for setting the power status of the ports. Assign a list to enable or disable each port. * 0 to disable power or other to enable power. **listsize**: The array must contain nums elements (nums is acquired from the return value of AVS_PoEGetPortNums).	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.4.3 AVS_PoEGetPortEnable

Function Name	AVS_PoEGetPortEnable
Purpose	Retrieves PoE state.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoEGetPortEnable(void* handle, int* list, unsigned int listsize)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **list**: An array for receiving the power status of the ports. **listsize**: The array must contain nums elements (nums is acquired from the return value of AVS_PoEGetPortNums).	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.4.4 AVS_PoESetPowConsumCalcModel

Function Name	AVS_PoESetPowConsumCalcModel
Purpose	Controls power budget mode.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoESetPowConsumCalcModel(void* handle, int usePowClassBudget)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **usePowClassBudget**: 0: calculate the Consumed Power Budget by PoE power consumption. 1: calculate the Consumed Power Budget by PoE Class.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.4.5 AVS_PoEGetPowConsumCalcModel

Function Name	AVS_PoEGetPowConsumCalcModel
Purpose	Retrieves power budget mode.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoEGetPowConsumCalcModel(void* handle, int* usePowClassBudget)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **usePowClassBudget**: 0: calculate the Consumed Power Budget by PoE power consumption. 1: calculate the Consumed Power Budget by PoE Class.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.4.6 AVS_PoESetProtectTempRange

Function Name	AVS_PoESetProtectTempRange
Purpose	Controls High Temperature (HT) and Recovery Temperature (RT). When HT is reached, automatically shuts down PoE power until the temperature sensor falls below RT.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoESetProtectTempRange(void* handle, int high_temperature, int recovery_temperature)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **high_temperature**: High temperature setting, more than or equal to 80°C, not exceeding 130°C, and at least 10°C higher than the Recovery Temperature setting. **recovery_temperature**: Recovery temperature setting, equal to or exceeding 70°C and at least 10°C lower than the high_temperature setting.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.4.7 AVS_PoEGetProtectTempRange

Function Name	AVS_PoEGetProtectTempRange
Purpose	Retrieves of High Temperature and Recovery Temperature.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoEGetProtectTempRange(void* handle, int high_temperature, int recovery_temperature)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **high_temperature**: High Temperature setting. **recovery_temperature**: Recovery Temperature setting.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.4.8 AVS_PoEGetProperty

Function Name	AVS_PoEGetProperty
Purpose	Retrieves PoE properties.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoEGetProperty(void* handle, AVS_POEPROPERTY_TYPE property, float* value)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. property & value: Refer to the following table.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

Property	**Value**
AVS_POEPROPERTY_POEHWSETTING	0: PoE-PSE HW setting disabled 1: PoE-PSE HW setting enabled
AVS_POEPROPERTY_POEINITIALSTATE	0: PoE-PSE should be turned off when powered on 1: PoE-PSE should be turned on when powered on
AVS_POEPROPERTY_OVERTEMPERATURE	0: no interrupt 1: over temperature interrupt arise
AVS_POEPROPERTY_CURRENTTEMPERATURE	Thermal temperature in °C.
AVS_POEPROPERTY_CONSUMEPOWER	Consumed power budget in W.
AVS_POEPROPERTY_REMAINPOWER	Remaining available power in W.
AVS_POEPROPERTY_POWERBUDGET	Total Budget in W.
AVS_POEPROPERTY_NUMS	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.4.9 AVS_PoEGetPortProperty

Function Name	AVS_PoEGetPortProperty
Purpose	Retrieves PoE port properties.
Category	Power over Ethernet
Header File	PoE.h
Syntax (C/C++)	int AVS_PoEGetPortProperty(void* handle, unsigned int port, AVS_POEPORTPROPERTY_TYPE property, float* value)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **port**: Indicates port number from 0 to N-1. (N is the number of port) property & value: Refer to the following table.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

String Identifier	**Value**
AVS_POEPORTPROPERTY_CURRENT	Port PoE power current (unit: A)
AVS_POEPORTPROPERTY_VOLT	Port PoE power voltage (unit: V)
AVS_POEPORTPROPERTY_POECLASS	Port PoE Class
AVS_POEPORTPROPERTY_POWERGOOD	Port Power Good means the power is on and stable.
AVS_POEPORTPROPERTY_LASTPOWERSTATE	0: PoE power off 1: PoE power on

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5 Trigger over Ethernet

ToE sends preconfigured ToE action commands to a GigE Vision camera when detecting a rising/falling edge of an external trigger signal. Users can also force the software ToE action commands via AVS SDK. The following shows the basic steps.

Procedure	AVS Function Name
1. Select Trigger Source	AVS_ToESetTriggerSource
2. Configure Action Command	AVS_ToESetActionCommand
3. Set Trigger Activation	AVS_ToESetTriggerActivation
4. Enable ToE function	AVS_ToESetTriggerEnable
5. Manually send ToE	AVS_ToESendActionCommand
6. ToE counters	AVS_ToEGetTriggerCount

3.2.5.1 AVS_ToEGetPortNums

Function Name	AVS_ToEGetPortNums
Purpose	Retrieves the number of ToE ports.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEGetPortNums(void* handle, unsigned int* nums)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **nums**: Number of ToE ports.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.5.2 AVS_ToESendActionCommand

Function Name	AVS_ToESendActionCommand
Purpose	Sends a software ToE action command over the selected port.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToESendActionCommand(void* handle, unsigned int port)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **port**: Indicates port number from 0 to N-1. (N is the number of port) -1 indicates to send ToE action command over all ports.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.3 AVS_ToESetActionCommand

Function Name	AVS_ToESetActionCommand
Purpose	Configures ToE action command for each port.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToESetActionCommand(void* handle, unsigned int port, unsigned long devicekey, unsigned long groupkey, unsigned long groupmask)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **port**: Indicates port number from 0 to N-1. (N is the number of port) **Devicekey**: 32-bit number of your choice, the key must be unique among all cameras in the network segment. The Devicekey on the camera should be the same on the card. **Groupkey**: A 32-bit number of your choice used to define a group of devices on which an action should be executed. If the action group key on the camera and the action group key in the protocol message are identical, the camera executes the corresponding action. The Groupkey on the camera should be the same on the card. **Groupmask**: A 32-bit number of your choice used to filter out a sub-group of cameras belonging to a group of cameras. The cameras belonging to a sub-group execute an action at the same time. The Groupmask on the camera should be the same on the card.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.4 AVS_ToEGetActionCommand

Function Name	AVS_ToEGetActionCommand
Purpose	Retrieves ToE action command for each port.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEGetActionCommand(void* handle, unsigned int port, unsigned long* devicekey, unsigned long* groupkey, unsigned long* groupmask)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **port**: Indicates port number from 0 to N-1. (N is the number of port) **Devicekey**: Retrieves Devicekey on the card. **Groupkey**: Retrieves Groupkey on the card. **Groupmask**: Retrieves Groupmask on the card.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.5.5 AVS_ToESetTriggerSource

Function Name	AVS_ToESetTriggerSource
Purpose	Configures ToE function source.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToESetTriggerSource(void* handle, int source)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **source**: 0: Software trigger source 1: External hardware trigger source	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.6 AVS_ToEGetTriggerSource

Function Name	AVS_ToEGetTriggerSource
Purpose	Acquires ToE function source.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEGetTriggerSource(void* handle, int *source)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **source**: 0: Software trigger source 1: External hardware trigger source	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.5.7 AVS_ToESetTriggerEnable

Function Name	AVS_ToESetTriggerEnable
Purpose	Enable ToE function.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToESetTriggerEnable(void* handle, int enable)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **enable**: 0: Disable ToE function 1: Enable ToE function	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.8 AVS_ToEGetTriggerEnable

Function Name	AVS_ToEGetTriggerEnable
Purpose	Retrieves ToE function.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEGetTriggerEnable(void* handle, int *enable)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **enable**: 0: Disable ToE function 1: Enable ToE function	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.9 AVS_ToESetTriggerActivation

Function Name	AVS_ToESetTriggerActivation
Purpose	Retrieves ToE function status.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToESetTriggerActivation(void* handle, AVS_EDGETRIGGER_TYPE edgetrigger)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **edgetrigger**: Set the edge trigger mode AVS_EDGETRIGGER_TYPE. Refer to following table.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

String Identifier	Parameter
AVS_EDGETRIGGER_RISINGEDGE	Signal rising edge trigger
AVS_EDGETRIGGER_FALLINGEDGE	Signal falling edge trigger
AVS_EDGETRIGGER_CHANGINGEDGE	Signal changing edge trigger

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.10 AVS_ToEGetTriggerActivation

Function Name	AVS_ToEGetTriggerActivation
Purpose	Acquires ToE trigger activation mode of ToE, specifying that the source trigger is considered valid on the rising or falling edge.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEGetTriggerActivation (void* handle, AVS_EDGETRIGGER_TYPE* edgetrigger)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **edgetrigger**: Refer to following table.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

String Identifier	**Parameter**
AVS_EDGETRIGGER_RISINGEDGE	Signal rising edge trigger
AVS_EDGETRIGGER_FALLINGEDGE	Signal falling edge trigger
AVS_EDGETRIGGER_CHANGINGEDGE	Signal changing edge trigger

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.11 AVS_ToESetOneTriggerAllMode

Function Name	AVS_ToESetOneTriggerAllMode
Purpose	Sets ToE trigger mode, where 4 to 4 mode indicates that each pin of the DI performs corresponding port action command to active, and 1 to 4 mode indicates that DI_0 performs all port action commands to active.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToESetOneTriggerAllMode(void* handle, int *enable)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **enable**: 0: N to N mode (N is the number of port) 1: 1 to N mode (N is the number of port)	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.12 AVS_ToEGetOneTriggerAllMode

Function Name	AVS_ToEGetOneTriggerAllMode
Purpose	Acquires ToE trigger mode, where 4 to 4 mode indicates that each pin of the DI performs corresponding port action command to active, and 1 to 4 mode indicates that DI_0 performs all port action commands to active.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToESetOneTriggerAllMode(void* handle, int *enable)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **enable**: 0: N to N mode (N is the number of port) 1: 1 to N mode (N is the number of port)	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.5.13 AVS_ToESetExTriggerDebounce

Function Name	AVS_ToESetExTriggerDebounce
Purpose	Sets trigger de-bounce time for filtering the external trigger.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToESetExTriggerDebounce(void* handle, unsigned long debounce)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **debounce**: Set the debounce time, input range: 0x0 - 0xFFFFFF.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.14 AVS_ToEGetExTriggerDebounce

Function Name	AVS_ToEGetExTriggerDebounce
Purpose	Acquires trigger de-bounce time for filtering the external trigger.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEGetExTriggerDebounce(void* handle, unsigned long* debounce)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **debounce**: The debounce time, range: 0x0 - 0xFFFFFF.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.5.15 AVS_ToEGetExTriggerDebounceUnit

Function Name	AVS_ToEGetExTriggerDebounceUnit
Purpose	Acquires trigger de-bounce unit in nano second.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEGetExTriggerDebounceUnit(void* handle, unsigned long* nanosec)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **nanosec**: Time in nano second.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3.2.5.16 AVS_ToEGetTriggerCount

Function Name	AVS_ToEGetTriggerCount
Purpose	Acquires trigger count, directing 16-bit counter to count triggers originating from hardware or software and ToE commands sent from the card.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEGetTriggerCount(void* handle, unsigned int port, unsigned int* triggerincount, unsigned int* triggeroutcount)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle. **port**: Indicates port number from 0 to N-1. (N is the number of port) **triggerincount**: Number of triggers from hardware trigger or software trigger (Valid value: 0 to 65535) **triggeroutcount**: Number of action commands from the card (Valid value: 0 to 65535)	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

3.2.5.17 AVS_ToEResetTriggerCount

Function Name	AVS_ToEResetTriggerCount
Purpose	Resets trigger count, with trigger counters reset to 0.
Category	Trigger over Ethernet
Header File	ToE.h
Syntax (C/C++)	int AVS_ToEResetTriggerCount (void* handle)
Parameter(s)	
handle: Acquired from the return value of AVS_GetProductHandle.	
Return Code	
No error occurs if the return value >= 0, or a negative value. See **Chapter 2 AVS Parameters Reference** for more information about return codes.	

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

This page intentionally left blank.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Important Safety Instructions

For user safety, please read and follow all instructions, Warnings, Cautions, and Notes marked in this manual and on the associated device before handling/operating the device, to avoid injury or damage.

S'il vous plaît prêter attention stricte à tous les avertissements et mises en garde figurant sur l'appareil , pour éviter des blessures ou des dommages.

- Read these safety instructions carefully
- Keep the User's Manual for future reference
- Read the Specifications section of this manual for detailed information on the recommended operating environment
- The device can be operated at an ambient temperature of 50ºC
- When installing/mounting or uninstalling/removing device; or when removal of a chassis cover is required for user servicing:
  - Turn off power and unplug any power cords/cables
  - Reinstall all chassis covers before restoring power
- To avoid electrical shock and/or damage to device:
  - Keep device away from water or liquid sources
  - Keep device away from high heat or humidity
  - Keep device properly ventilated (do not block or cover ventilation openings)
  - Always use recommended voltage and power source settings
  - Always install and operate device near an easily accessible electrical outlet
  - Secure the power cord (do not place any object on/over the power cord)
  - Only install/attach and operate device on stable surfaces and/or recommended mountings
- If the device will not be used for long periods of time, turn off and unplug from its power source

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

- Never attempt to repair the device, which should only be serviced by qualified technical personnel using suitable tools
- A Lithium-type battery may be provided for uninterrupted backup or emergency power.



Risk of explosion if battery is replaced with one of an incorrect type; please dispose of used batteries appropriately.
Risque d'explosion si la pile est remplacée par une autre de type incorrect. Veuillez jeter les piles usagées de façon appropriée.

- The device must be serviced by authorized technicians when:
  - The power cord or plug is damaged
  - Liquid has entered the device interior
  - The device has been exposed to high humidity and/or moisture
  - The device is not functioning or does not function according to the User's Manual
  - The device has been dropped and/or damaged and/or shows obvious signs of breakage
- Disconnect the power supply cord before loosening the thumbscrews and always fasten the thumbscrews with a screwdriver before starting the system up
- It is recommended that the device be installed only in a server room or computer room where access is:
  - Restricted to qualified service personnel or users familiar with restrictions applied to the location, reasons therefor, and any precautions required
  - Only afforded by the use of a tool or lock and key, or other means of security, and controlled by the authority responsible for the location
- If PoE (Power over Ethernet) is enabled for the device, the system can ONLY be deployed indoors. Unless otherwise noted, the PoE system is NOT designed to withstand the rigors of outdoor use.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

	**BURN HAZARD** Touching this surface could result in bodily injury. To reduce risk, allow the surface to cool before touching. ***RISQUE DE BRÛLURES*** *Ne touchez pas cette surface, cela pourrait entraîner des blessures.* *Pour éviter tout danger, laissez la surface refroidir avant de la toucher.*

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

This page intentionally left blank.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Getting Service

Ask an Expert: http://askanexpert.adlinktech.com

ADLINK Technology, Inc.
No. 66, Huaya 1st Rd., Guishan District
Taoyuan City 333411, Taiwan
Tel: +886-3-216-5088
Fax: +886-3-328-5706
Email: service@adlinktech.com

Ampro ADLINK Technology, Inc.
6450 Via Del Oro
San Jose, CA 95119-1208, USA
Tel: +1-408-360-0200
Toll Free: +1-800-966-5200 (USA only)
Fax: +1-408-600-1189
Email: info@adlinktech.com

ADLINK Technology (China) Co., Ltd.
300 Fang Chun Rd., Zhangjiang Hi-Tech Park
Pudong New Area, Shanghai, 201203 China
Tel: +86-21-5132-8988
Fax: +86-21-5132-3588
Email: market@adlinktech.com

ADLINK Technology GmbH
Hans-Thoma-Straße 11
D-68163 Mannheim, Germany
Tel: +49-621-43214-0
Fax: +49-621 43214-30
Email: emea@adlinktech.com

Please visit the Contact page at www.adlinktech.com for information on how to contact the ADLINK regional office nearest you:

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000