
PXES-2301
6-slot PXI Express Chassis


Getting Started



I/O & Indicators



A	Power
B	Chassis Status LED
C	Fan Switch
D	Universal Power
E	Chassis Ground Lug



Package Contents

- Quick Start Guide (this document)
- PXES-2301 chassis
- Power cords
- Filler panel kit for unused/reserved slots incl. five 1-slot panels

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

IMPORTANT SAFETY INFORMATION

For user safety, please read and follow all instructions, WARNINGS, CAUTIONS, and NOTES here, in the accompanying manual, and on the associated device before handling/operating the device.
Read the specifications section of the User's Manual for detailed information on the operating environment of this device
When installing/mounting or uninstalling/removing device, turn off power and unplug any power cords/cables
Never attempt to repair the device, which can only be serviced by qualified personnel

Service by authorized technicians is required when:
The power cord or plug is damaged
Liquid has been introduced to the device interior
The device has been exposed to high humidity/moisture
The device is not functioning or does not function according to the manual
The device has been dropped and/or damaged
The device shows obvious signs of breakage


To avoid electrical shock and/or damage to the device:
Keep the device away from water or liquid sources
Keep the device away from high heat or high humidity
Keep the device properly ventilated (do not block or cover
ventilation openings)
Ensure use of recommended voltage and power source settings
Always install and operate the device near an easily accessible electrical socket-outlet
Secure the power cord (do not place any objects on/over the power cord)
Install/attach and operate the device only on stable surfaces and/or recommended mountings

If the device is to remain idle for long periods of time, turn off the device and unplug from power source

Downloads

At ADLINK's website WWW.ADLINKTECH.COM

Enter "PXES-2301" and choose "Download", as shown



Materials available include documentation, utilities, and others.

Contact ADLINK

Web: http://www.adlinktech.com
Service: service@adlinktech.com

Tel: +886-2-8226-5877
Fax: +886-2-8226-3337

Copyright 2016 ADLINK Technology, Inc.
Contents and specifications subject to change without notice.

ADLINK TECHNOLOGY INC.

Advance Technologies
Automate the World

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000