RK-606UC Chassis Manual

INDEX

INDEX **P1**


PACKING CONTAIN **P2**



INSTALLATION GUIDE **P3-P6**


LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


PACKING CONTAIN	
Chassis Front View	
Chassis Rear View	
Packing Bag 1	
Packing Bag 2	
Rubber Foot* 4	
機箱側邊固定架	待補照片

INSTALLATION GUIDE

Remove Screws	
Open Chassis up cover	
Fixed Backplane with Screws	

Fixed Power with Holder Bracket	  
Plug ATX 20 Pin connector into Socket	
Take User's SBC	

Plug in **HD LED** **Power LED** **Rocker SW** **on SBC**	   
Plug in Front Access USB on SBC	
Remove Drive Bay	 

Fixed HD / FDD CD-Rom on Drive with Screws	 
Add HD Cable	
Screw back onto Chassis	